

---

# Master Index

## A

addnode utility, *ULTRIX*, 2-7; *OSF/1*, 2-8  
Adobe fonts, *SunOS*, 2-11  
Alias names, *ULTRIX*, 2-13; *OSF/1*, 2-13;  
*SunOS*, 2-13; *HP-UX*, 2-11; *AIX*, 2-12;  
*SCO*, 2-12  
Application launcher, *Overview*, 1-3, 1-19;  
*OpenVMS*, 2-18; *ULTRIX*, 2-28;  
*OSF/1*, 2-27; *SunOS*, 2-24; *HP-UX*,  
2-18; *AIX*, 2-24; *SCO*, 2-22  
DEC OSF/1 AXP systems, *Appendixes*,  
B-2  
*ULTRIX* systems, *Appendixes*, B-2  
UNIX systems, *Appendixes*, B-2  
Audience  
of this guide, *Overview*, vii

## B

Backing up settings  
terminal settings, *Managing*, 3-40  
work group settings, *Managing*, 3-38  
Backing up terminals, *Managing*, 3-4  
Backup  
OpenVMS system disk, *OpenVMS*, 1-5  
Backup icon, *Managing*, 3-5  
Backup Terminal dialog box (CM),  
*Managing*, 3-41  
Backup Work Group dialog box (CM),  
*Managing*, 3-39  
BDF font format  
conversion, *OpenVMS*, 2-10  
converting to PCF, *ULTRIX*, 2-11;  
*OSF/1*, 2-11; *SunOS*, 2-10; *HP-UX*,  
2-9; *AIX*, 2-10; *SCO*, 2-10  
Bill of materials  
InfoServer system, *InfoServer*, 1-1  
BOOT commands, *Appendixes*, A-1  
clearing the booting method, *ULTRIX*,  
2-6, 2-7; *OSF/1*, 2-6, 2-8;  
*Appendixes*, A-2  
displaying the >>> prompt, *Appendixes*,  
A-1  
entering, *Appendixes*, A-1

## BOOT commands (cont'd)

IP, *ULTRIX*, 2-6; *OSF/1*, 2-6; *SunOS*,  
2-7; *HP-UX*, 2-7; *AIX*, 2-8; *SCO*,  
2-8  
MOP by file name, *OpenVMS*, 2-7  
MOP by name, *ULTRIX*, 2-7; *OSF/1*,  
2-8  
OpenVMS  
MOP by Ethernet address, *OpenVMS*,  
2-6  
rebooting the terminal, *Appendixes*, A-3  
VXT software, *Appendixes*, A-1  
Booting terminals, *InfoServer*, 2-3;  
*OpenVMS*, 2-3; *ULTRIX*, 2-3; *OSF/1*,  
2-3; *SunOS*, 2-3; *HP-UX*, 2-3; *AIX*,  
2-3; *SCO*, 2-3  
creating directories for VXT images,  
*ULTRIX*, 2-3; *OSF/1*, 2-3; *SunOS*,  
2-3; *HP-UX*, 2-3; *AIX*, 2-3; *SCO*,  
2-3  
Customize Boot dialog box, *Overview*,  
1-13  
error codes, *Appendixes*, A-3  
host-based terminal, *Overview*, 1-9  
MOP, *ULTRIX*, 2-6; *OSF/1*, 2-7  
by Ethernet address, *ULTRIX*, 2-7;  
*OSF/1*, 2-8  
by VXT image name, *ULTRIX*, 2-6;  
*OSF/1*, 2-7  
remote node, *ULTRIX*, 2-8; *OSF/1*,  
2-9  
overview, *Overview*, 1-2  
remote node, *OpenVMS*, 2-7  
server-based terminal, *Overview*, 1-10  
VXT system image names, *Overview*, 1-12  
with IP, *ULTRIX*, 2-3; *OSF/1*, 2-3;  
*SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4;  
*SCO*, 2-3  
bootp command, *ULTRIX*, 2-3; *OSF/1*, 2-4;  
*SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4;  
*SCO*, 2-4  
BOOTP daemon, *ULTRIX*, 2-2; *OSF/1*,  
2-2; *SunOS*, 2-2; *HP-UX*, 2-2; *AIX*,  
2-2; *SCO*, 2-2; *Appendixes*, B-2

- BOOTP daemon (cont'd)
  - creating command entries, *ULTRIX*, 2-3; *OSF/1*, 2-4; *SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4; *SCO*, 2-4
- /bootpd file, *SunOS*, 2-6; *HP-UX*, 2-7; *AIX*, 2-7; *SCO*, 2-8
- BOOTP/TFTP protocol, *InfoServer*, 2-3
- BOOTP/TFTP transport
  - downloading VXT images, *Overview*, 1-11
- BOOTP transport
  - network access, *Overview*, 1-7
- Boot settings
  - customizing, *Managing*, 3-27
- Bridge
  - effect on VXT loader file, *Overview*, 1-8
- BYPASS privilege, *OpenVMS*, 1-2

## C

- Change Terminal Password dialog box (CM), *Managing*, 3-44
- Change Work Group Password dialog box (CM), *Managing*, 3-43
- Character cell terminal services, *Overview*, 1-7; *OpenVMS*, 2-15; *ULTRIX*, 2-19; *OSF/1*, 2-19; *SunOS*, 2-19; *HP-UX*, 2-13; *AIX*, 2-19; *SCO*, 2-17
  - requirements, *Overview*, 1-7
- Color
  - customizing, *Managing*, 2-12
- Communication
  - protocols, *Overview*, 1-2
- Composite resource file, *Overview*, 1-3; *Managing*, 2-2
  - creating, *Managing*, 2-5
- Configuration
  - host system
    - booting terminals, *ULTRIX*, 2-3, 2-6; *OSF/1*, 2-3, 2-7; *SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4; *SCO*, 2-3
- Configuration management, *Overview*, 1-15, 1-18
- Configuration manager, *Managing*, 3-1 to 3-52
  - compared to host-based resource file, *Managing*, 1-1
  - Create Font Set dialog box, *Managing*, 3-49
  - features, *Managing*, 1-1
  - Font Management dialog box, *Managing*, 3-47
  - Resource Management dialog box, *Managing*, 3-8
  - Version 2.1 features, *Managing*, 3-1

- Console prompt
  - entering BOOT commands, *Appendixes*, A-1
- Conventions
  - used in this guide, *Overview*, x
- convertfont utility, *SunOS*, 2-11
- Copy Font Set dialog box (CM), *Managing*, 3-51
- Copying
  - font sets, *Managing*, 3-51
  - terminal settings, *Managing*, 3-31
  - work group settings, *Managing*, 3-29
- Copy Terminal dialog box (CM), *Managing*, 3-31
- Copy Work Group dialog box (CM), *Managing*, 3-29
- Create Font Set dialog box (CM), *Managing*, 3-49
- Create menu (CM), *Managing*, 3-8, 3-10
  - creating terminals, *Managing*, 3-12
- Create Terminal dialog box (CM), *Managing*, 3-12
- Create Work Group dialog box (CM), *Managing*, 3-10
- Creating
  - font sets, *Managing*, 3-49
  - terminals, *Managing*, 3-12
  - work groups, *Managing*, 3-10
- Cterm
  - X services, *OpenVMS*, 2-15
- Customization file
  - See* Resource file
- Customizations, *Overview*, 1-3
  - host-based terminals, *Overview*, 1-3
  - server-based terminals, *Overview*, 1-5
- Customize AutoStart dialog box, *Overview*, 1-16
- Customize Boot dialog box, *Overview*, 1-13
- Customize menu (TM)
  - Font Management dialog box, *Managing*, 3-47
  - Resource Management dialog box, *Managing*, 3-8
- Customize Resource Files dialog box, *Managing*, 2-6
- Customize Serial and Parallel Ports dialog box, *OpenVMS*, 2-17
- Customize Software Options dialog box, *Overview*, 1-18
- Customize Terminal dialog box (CM), *Managing*, 3-23
- Customize Work Group dialog box (CM), *Managing*, 3-22
- Customizing
  - terminals, *Managing*, 3-20
  - work groups, *Managing*, 3-20

- Customizing
  - work groups (cont'd)
    - Terminal Manager window, *Managing*, 3-24
    - VXT DECterm window, *Managing*, 3-25
    - window manager, *Managing*, 3-26

## D

---

- Daemon
  - BOOTP, *ULTRIX*, 2-3; *OSF/1*, 2-4; *SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4; *SCO*, 2-4
  - Internet, *ULTRIX*, 2-4; *SunOS*, 2-4; *AIX*, 2-4; *SCO*, 2-4
  - printer, *ULTRIX*, 2-24; *OSF/1*, 2-22; *SunOS*, 2-21; *HP-UX*, 2-15
  - system log, *ULTRIX*, 2-4; *OSF/1*, 2-4; *SunOS*, 2-4; *HP-UX*, 2-4
  - TFTP, *ULTRIX*, 2-4; *OSF/1*, 2-4; *SunOS*, 2-4; *HP-UX*, 2-4
- DDS distribution media, *HP-UX*, 1-1, 1-6
- DECnet transport, *OpenVMS*, 2-5
  - customizing terminal settings, *Overview*, 1-18
  - for a remote installation, *ULTRIX*, 1-9; *OSF/1*, 1-10
  - for terminal windows, *ULTRIX*, 2-19; *OSF/1*, 2-19
- Mirror, *OpenVMS*, 2-14
- Network Management Listener, *Overview*, 1-8; *OpenVMS*, 2-14
- troubleshooting, *OpenVMS*, 2-14
- using, *Managing*, 3-27
- VXT\$SERVER object, *OpenVMS*, 2-14
- X services, *OpenVMS*, 2-12
- X sessions
  - connection logic, *OpenVMS*, 2-13
  - X session support, *OpenVMS*, 1-12
- DEC OSF/1 AXP operating system
  - character cell terminal services, *OSF/1*, 2-19
  - DECnet access, *OSF/1*, 2-19
  - DEC OSF/1 V1.2 Worksystem Software
    - version, *OSF/1*, 1-2
    - downloading VXT software, *OSF/1*, 2-3
    - error messages, *Appendixes*, C-1 to C-4
    - files installed, *Appendixes*, B-1 to B-11
    - fonts
      - support requirements, *Overview*, 1-14
    - hardware requirements, *OSF/1*, 1-2
    - installing VXT software on, *OSF/1*, 1-1
    - LAT access, *OSF/1*, 2-19
    - LAT printer port setup, *OSF/1*, 2-21
    - local installation

- DEC OSF/1 AXP operating system
  - local installation (cont'd)
    - from TK50 or magnetic tape, *OSF/1*, 1-8
    - network requirements, *Overview*, 1-7
    - print command, *OSF/1*, 2-26
    - required version, *OSF/1*, 1-1
    - sample VXT software installation, *OSF/1*, 1-13
    - system administration checklist, *OSF/1*, 2-1
    - system management tasks, *OSF/1*, 2-1
    - TCP/IP printer port setup, *OSF/1*, 2-21
    - XDMCP support, *OSF/1*, 2-14
- DEC OSF/1 worksystem software, *OSF/1*, 1-2
- Deleting
  - work groups and terminals, *Managing*, 3-45
- Diagnostics
  - network, *Overview*, 1-8
- Directory
  - for VXT images, *ULTRIX*, 2-3; *OSF/1*, 2-3; *SunOS*, 2-3; *HP-UX*, 2-3; *AIX*, 2-3; *SCO*, 2-3
- Disk space requirements
  - installation, *InfoServer*, 1-2; *OpenVMS*, 1-4; *ULTRIX*, 1-4; *OSF/1*, 1-5; *SunOS*, 1-4; *HP-UX*, 1-4; *AIX*, 1-4; *SCO*, 1-5
- Display color
  - customizing, *Managing*, 2-12
- Display language, *Overview*, 1-19
- Documentation, *InfoServer*, 2; *OpenVMS*, 2; *ULTRIX*, 2; *OSF/1*, 2; *SunOS*, 2; *HP-UX*, 2; *AIX*, 2; *SCO*, 2
  - related documents, *Overview*, ix
- Downloading VXT software
  - methods, *Overview*, 1-11
  - overview, *Overview*, 1-9

## E

---

- Error codes
  - booting, *Appendixes*, A-3
- Error messages
  - installation
    - UNIX systems, *Appendixes*, C-1 to C-4
    - subset installation, *Appendixes*, C-1
- Error recovery
  - IBM AIX system, *AIX*, 1-9
  - installation, *OpenVMS*, 1-13
- Errors
  - installation, *HP-UX*, 1-10

- /etc/bootptab file, *ULTRIX*, 2-4, 2-5; *OSF/1*, 2-4, 2-6; *SunOS*, 2-5; *HP-UX*, 2-5; *AIX*, 2-5; *SCO*, 2-5, 2-8
- example, *SunOS*, 2-5; *HP-UX*, 2-5
- examples, *ULTRIX*, 2-5; *AIX*, 2-5; *SCO*, 2-5
- /etc/exports file, *ULTRIX*, 2-10; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-10
- /etc/hosts, *ULTRIX*, 2-1; *OSF/1*, 2-1; *AIX*, 2-1; *SCO*, 2-1
- /etc/hosts file, *SunOS*, 2-1; *HP-UX*, 2-1
- /etc/inetd.conf file, *ULTRIX*, 2-5; *OSF/1*, 2-5
- /etc/printcap, *SunOS*, 2-22
- /etc/rc2.d/S80lp file, *SCO*, 2-21
- /etc/services file, *ULTRIX*, 2-5; *OSF/1*, 2-5; *SunOS*, 2-6; *HP-UX*, 2-7; *AIX*, 2-7; *SCO*, 2-8
- Ethernet address
  - for booting VXT software, *Overview*, 1-11, 1-12; *ULTRIX*, 2-7; *OSF/1*, 2-8

## F

- Factory-default settings
  - resetting in memory, *Appendixes*, A-2
- File menu (CM), *Managing*, 3-8, 3-14
- Find Terminal dialog box, *Managing*, 3-17
- Find Work Group dialog box, *Managing*, 3-16
- Find Terminal dialog box (CM), *Managing*, 3-17
- Find Work Group dialog box (CM), *Managing*, 3-16
- fixSunfonts utility, *SunOS*, 2-12
- Font, *Overview*, 1-2
  - access, *Overview*, 1-13, 1-17; *InfoServer*, 2-8; *OpenVMS*, 2-9; *ULTRIX*, 2-9; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-9
  - NFS, *AIX*, 2-10
  - compilation and conversion, *Overview*, 1-14; *InfoServer*, 2-8
  - compiling, *OpenVMS*, 2-10
    - BDF to PCF, *OpenVMS*, 2-10; *ULTRIX*, 2-11; *OSF/1*, 2-11; *SunOS*, 2-10; *HP-UX*, 2-9; *AIX*, 2-10; *SCO*, 2-10
    - BDF to SNF, *OpenVMS*, 2-10
    - Sun to BDF, *SunOS*, 2-12
    - TFTP systems, *ULTRIX*, 2-10, 2-11; *OSF/1*, 2-11; *SunOS*, 2-9; *HP-UX*, 2-9; *AIX*, 2-10; *SCO*, 2-10
  - conversion

## Font

- conversion (cont'd)
  - Sun fonts, *SunOS*, 2-11
- convertfont utility, *SunOS*, 2-11
- daemon, *OpenVMS*, 2-9
- DEC OSF/1 AXP fonts, *OSF/1*, 2-10
- fixSunfonts utility, *SunOS*, 2-12
- font aliases, *ULTRIX*, 2-13; *OSF/1*, 2-13; *SunOS*, 2-13; *HP-UX*, 2-11; *AIX*, 2-12; *SCO*, 2-12
- font path
  - restricted tftp, *ULTRIX*, 2-9; *SunOS*, 2-8; *HP-UX*, 2-8; *SCO*, 2-9
  - unrestricted tftp, *ULTRIX*, 2-9; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-9
- fonts.alias file, *SunOS*, 2-12
- font server, *Overview*, 1-17
- format
  - PCF, *OpenVMS*, 2-9; *ULTRIX*, 2-10; *OSF/1*, 2-10; *SunOS*, 2-9; *HP-UX*, 2-9; *AIX*, 2-9; *SCO*, 2-10
  - SNF, *OpenVMS*, 2-9
  - Sun fonts, *SunOS*, 2-11
- formats supported, *Overview*, 1-13
- in VXT kits, *Overview*, 1-14
- makeafb utility, *SunOS*, 2-12
- management, *ULTRIX*, 2-13; *OSF/1*, 2-12; *SunOS*, 2-13; *HP-UX*, 2-11; *AIX*, 2-11; *SCO*, 2-12
- managing, *Managing*, 3-47 to 3-52
- requirements, *Overview*, 1-13
- Sun Families.list file, *SunOS*, 2-12
- ULTRIX fonts, *ULTRIX*, 2-10
- UNIX fonts, *ULTRIX*, 2-10; *OSF/1*, 2-10; *SunOS*, 2-9; *HP-UX*, 2-9; *AIX*, 2-9; *SCO*, 2-10
- VXT DECterm fonts, *OpenVMS*, 1-20
- X11R5 server support, *Overview*, 1-17
- XLFD names, *ULTRIX*, 2-13; *OSF/1*, 2-13; *SunOS*, 2-13; *HP-UX*, 2-11; *AIX*, 2-12; *SCO*, 2-12
- Font Management dialog box (CM), *Managing*, 3-47
  - Copy Font Set dialog box, *Managing*, 3-51
  - Create Font Set dialog box, *Managing*, 3-49
  - exiting from, *Managing*, 3-52
- Font names
  - listing, *Managing*, 3-47, 3-52
- Font paths
  - NFS, *ULTRIX*, 2-10; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-10



## Font paths (cont'd)

TFTP, *ULTRIX*, 2-9; *OSF/1*, 2-10;  
*SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9;  
*SCO*, 2-9

fonts.alias file, *ULTRIX*, 2-13; *OSF/1*,  
2-13; *SunOS*, 2-13; *HP-UX*, 2-11; *AIX*,  
2-12; *SCO*, 2-12

## Font set

copying, *Managing*, 3-51  
creating, *Managing*, 3-49  
removing, *Managing*, 3-52  
renaming, *Managing*, 3-51

Font set scroll box (CM), *Managing*, 3-47

Font utilities, *ULTRIX*, 2-10, 2-11; *OSF/1*,  
2-11; *SunOS*, 2-10; *HP-UX*, 2-9; *AIX*,  
2-10; *SCO*, 2-10

# H

---

## Halt button

location, *Appendixes*, A-1

## Hardware requirements

IBM AIX system, *AIX*, 1-2  
installation, *InfoServer*, 1-2; *OpenVMS*,  
1-2

SunOS system, *SunOS*, 1-2

## Help

installation, *OpenVMS*, 1-5

## Hewlett-Packard

See *HP-UX* system

## Host Accessible Printer Port button,

*OpenVMS*, 2-17

## Host application

launching, *Overview*, 1-19

## Host-based image

downloading methods, *Overview*, 1-9

## Host-based mode

### BOOT commands

VXT EX software, *Appendixes*, A-2

VXT software, *Appendixes*, A-2

## Host-based resource file, *Overview*, 1-3,

1-18; *Managing*, 2-1

adding other resources, *Managing*, 2-11

compared to configuration manager,  
*Managing*, 1-1

composite resource file, *Managing*, 2-5

creating, *Managing*, 2-2

Customize Resource Files dialog box,

*Managing*, 2-6

customizing display colors, *Managing*,  
2-12

customizing the window manager,  
*Managing*, 2-11

displaying the list of active files,  
*Managing*, 2-11

entering comments, *Managing*, 2-3

example, *Managing*, 2-4

## Host-based resource file (cont'd)

file name syntax, *Managing*, 2-7

format, *Managing*, 2-1

including other resource files, *Managing*,  
2-4

specifying, *Managing*, 2-6

substitute characters, *Managing*, 2-8

syntax, *Managing*, 2-3

template, *Managing*, 2-1, 2-2, 2-13

## Host-based system

configuration, *Overview*, 1-3

overview, *Overview*, 1-3

## Host-based terminal, *Managing*, 3-6

change password, *Managing*, 3-44

choosing for configuration, *Managing*,  
3-14

configuration manager, *Managing*, 3-6

terminal password, *Managing*, 3-7

finding for configuration, *Managing*, 3-16

host-based resource files, *Managing*, 2-1

managing, *Managing*, 1-3

## Host-based VXT software

booting, *InfoServer*, 2-5

## HP-UX operating system

character cell terminal services, *HP-UX*,  
2-13

downloading VXT software, *HP-UX*, 2-3

error messages, *Appendixes*, C-1 to C-4

files installed, *Appendixes*, B-1 to B-11

fonts

support requirements, *Overview*, 1-14

hardware requirements, *HP-UX*, 1-2

installing VXT software on, *HP-UX*, 1-1  
to 1-17

local installation

from DDS or magnetic tape, *HP-UX*,  
1-7

network requirements, *Overview*, 1-7

print command, *HP-UX*, 2-17

required version, *HP-UX*, 1-1

sample VXT software installation,  
*HP-UX*, 1-10

software requirements, *HP-UX*, 1-2

system administration checklist, *HP-UX*,  
2-1

system management tasks, *HP-UX*, 2-1

TCP/IP printer port setup, *HP-UX*, 2-15

# I

---

## IBM AIX operating system

character cell terminal services, *AIX*, 2-19

downloading VXT software, *AIX*, 2-3

error messages, *Appendixes*, C-1 to C-4

error recovery, *AIX*, 1-9

files installed, *Appendixes*, B-1 to B-11

fonts

## IBM AIX operating system

### fonts (cont'd)

support requirements, *Overview*, 1-14

installing VXT software on, *AIX*, 1-1 to 1-16

### local installation

from QIC 24 or magnetic tape, *AIX*, 1-7

network requirements, *Overview*, 1-7

print command, *AIX*, 2-23

required version, *AIX*, 1-1

sample VXT software installation, *AIX*, 1-10

software requirements, *AIX*, 1-2

system administration checklist, *AIX*, 2-1

system management tasks, *AIX*, 2-1

TCP/IP printer port setup, *AIX*, 2-21

XDMCP support, *AIX*, 2-13

## Icon

backup, *Managing*, 3-5, 3-38

backup terminal, *Managing*, 3-8

backup work group, *Managing*, 3-8

server, *Managing*, 3-8

terminal, *Managing*, 3-8

work group, *Managing*, 3-8

## Images

See System images

inetd.conf file, *ULTRIX*, 2-3; *OSF/1*, 2-4;

*SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4;

*SCO*, 2-4

## InfoReader library

files, *InfoServer*, 1-5, 1-8

online documents, *Overview*, 1-17

## InfoServer operating system

accessing, *InfoServer*, 2-2

booting terminals by Ethernet address, *InfoServer*, 2-5

### commands

CREATE SERVICE, *InfoServer*, 2-6

SET SERVER MOP ENABLED,  
*InfoServer*, 2-6

SET SERVER REMOTE DEVICES,  
*InfoServer*, 2-12

SHOW SERVER, *InfoServer*, 2-11

UPDATE VXT, *InfoServer*, 2-5, 2-9

configuration, *Overview*, 1-4

controlling file creation on, *InfoServer*, 2-11

disk space requirements, *InfoServer*, 1-2

downloading VXT software, *InfoServer*, 2-3

enabling remote devices, *InfoServer*, 2-12

finding services, *Managing*, 3-18

font access, *InfoServer*, 2-8

### fonts

compiling, *InfoServer*, 2-8

support requirements, *Overview*, 1-14

## InfoServer operating system (cont'd)

hardware requirements, *InfoServer*, 1-2

installing VXT software, *InfoServer*, 1-1

LASTport/Disk transport, *InfoServer*, 2-3

LASTport group code, *Managing*, 3-2

loading host-based VXT software,

*InfoServer*, 2-5

loading VXT versions, *InfoServer*, 2-4

management tasks, *InfoServer*, 2-1

MOP-filtering bridge, *InfoServer*, 2-3

network requirements, *Overview*, 1-7

paged memory requirements, *InfoServer*, 2-11

paging files, *InfoServer*, 2-11

password, *InfoServer*, 1-3, 2-9

purging VXT versions, *InfoServer*, 2-7

Remote Device List, *InfoServer*, 2-11

SHOW PARTITION command, *InfoServer*, 1-2, 1-6

software requirements, *InfoServer*, 1-2

UPDATE VXT command, *InfoServer*, 1-3

VXT loader file, *InfoServer*, 2-3

Installation, *InfoServer*, 1-1; *OpenVMS*,

1-1; *ULTRIX*, 1-1; *OSF/1*, 1-1;

*SunOS*, 1-1; *HP-UX*, 1-1; *AIX*, 1-1;

*SCO*, 1-1

error recovery, *ULTRIX*, 1-10; *OSF/1*,

1-11; *SunOS*, 1-9; *HP-UX*, 1-9;

*SCO*, 1-9

### files installed

for InfoServer system, *InfoServer*, 1-8

for OpenVMS system, *OpenVMS*, 1-19

for UNIX systems, *Appendixes*, B-1 to B-11

installation time, *InfoServer*, 1-1;

*OpenVMS*, 1-1; *ULTRIX*, 1-2;

*OSF/1*, 1-2; *SunOS*, 1-2; *HP-UX*,

1-2; *AIX*, 1-2; *SCO*, 1-2

local, *ULTRIX*, 1-7; *OSF/1*, 1-8;

*SunOS*, 1-7; *HP-UX*, 1-7; *AIX*, 1-7;

*SCO*, 1-7

new features, *Overview*, 1-17

remote, *ULTRIX*, 1-8; *OSF/1*, 1-9;

*SunOS*, 1-8; *HP-UX*, 1-8; *AIX*, 1-8

sample session, *ULTRIX*, 1-11; *OSF/1*,

1-13; *SunOS*, 1-11; *HP-UX*, 1-10;

*AIX*, 1-10; *SCO*, 1-11

for InfoServer system, *InfoServer*, 1-7

for OpenVMS AXP system, *OpenVMS*, 1-15

software requirements, *InfoServer*, 1-2

## Installation verification procedure

error recovery, *OpenVMS*, 1-13

running separately, *OpenVMS*, 1-14

instvxtfonts utility, *ULTRIX*, 2-12;  
*OSF/1*, 2-12; *SunOS*, 2-10; *HP-UX*,  
 2-10; *AIX*, 2-11; *SCO*, 2-11  
 Internet daemon, *ULTRIX*, 2-2, 2-4;  
*OSF/1*, 2-2; *SunOS*, 2-2, 2-4; *HP-UX*,  
 2-2; *AIX*, 2-2, 2-4; *SCO*, 2-2, 2-4  
 restarting, *ULTRIX*, 2-5; *OSF/1*, 2-6;  
*SunOS*, 2-7; *HP-UX*, 2-7; *AIX*, 2-7;  
*SCO*, 2-8  
 IP transport  
   in default booting sequence, *Overview*,  
   1-12  
   loading VXT software, *ULTRIX*, 2-3;  
   *OSF/1*, 2-3; *SunOS*, 2-4; *HP-UX*,  
   2-4; *AIX*, 2-4; *SCO*, 2-3  
   directories, *ULTRIX*, 2-3; *OSF/1*,  
   2-3; *SunOS*, 2-3; *HP-UX*, 2-3;  
   *AIX*, 2-3; *SCO*, 2-3  
   VXT boot commands, *ULTRIX*, 2-6;  
   *OSF/1*, 2-6; *SunOS*, 2-7; *HP-UX*,  
   2-7; *AIX*, 2-8; *SCO*, 2-8  
 IVP  
   *See* Installation verification procedure,  
   *OpenVMS*, 1-13

## K

Keyboard  
   Sun style, *Overview*, 1-19  
 Key name, in resource file, *Managing*, 2-5

## L

LAN bridge, *InfoServer*, 2-3  
 LASTport/Disk transport, *Overview*, 1-5;  
*InfoServer*, 2-3  
   font access, *Overview*, 1-6  
   network access, *Overview*, 1-7  
 LASTport group code, *Overview*, 1-18;  
*InfoServer*, 2-13; *Managing*, 3-2  
   customizing, *Managing*, 3-27  
 LASTport Group Code (CM), *Managing*,  
 3-14  
 LATCP file, *OpenVMS*, 2-20  
 LAT font daemon, *OpenVMS*, 2-9  
 LAT/Master  
   for OpenVMS operating system,  
   *InfoServer*, 1-2  
   for OpenVMS systems, *OpenVMS*, 2-20  
 LAT printer port, *OSF/1*, 2-21  
   OpenVMS setup, *OpenVMS*, 2-17  
   ULTRIX setup, *ULTRIX*, 2-21  
 LAT protocol  
   specifying font sets, *Managing*, 3-50

LAT responder, *Overview*, 1-8; *InfoServer*,  
 2-12  
 LAT service responder  
   for OpenVMS systems, *OpenVMS*, 2-20  
 LAT transport  
   font access, *OpenVMS*, 2-9  
   for terminal windows, *ULTRIX*, 2-19;  
   *OSF/1*, 2-19  
   network access, *Overview*, 1-7  
   X services, *OpenVMS*, 2-11  
 Launching applications, *Overview*, 1-3  
 Loading VXT software  
   *See* Booting  
   *See* Booting terminals  
 Local installation, *ULTRIX*, 1-7; *OSF/1*,  
 1-8; *SunOS*, 1-7; *HP-UX*, 1-7; *AIX*,  
 1-7; *SCO*, 1-7  
   for SunOS  
     from QIC 24 or magnetic tape, *SunOS*,  
     1-7  
 Local Terminals server, *Managing*, 3-6  
 Local work group, *Managing*, 3-6  
 Locking  
   customized settings, *Managing*, 3-22,  
   3-24  
   DECterm settings, *Managing*, 3-25  
   window manager settings, *Managing*,  
   3-26  
 Log file, *ULTRIX*, 2-4; *OSF/1*, 2-4;  
*SunOS*, 2-4; *AIX*, 2-4; *SCO*, 2-4  
 lpadmin command, *HP-UX*, 2-16; *SCO*,  
 2-20, 2-21  
 lp command, *HP-UX*, 2-17  
 lpr command, *ULTRIX*, 2-27; *OSF/1*, 2-26;  
*SunOS*, 2-23; *AIX*, 2-23  
 lprsetup command, *ULTRIX*, 2-22, 2-25;  
*OSF/1*, 2-23

## M

Maintenance menu (CM), *Managing*, 3-9,  
 3-43, 3-44  
 makeafb utility, *SunOS*, 2-12  
 Managing  
   fonts, *Managing*, 3-47 to 3-52  
   server-based terminals, *Managing*, 3-2  
   terminals, *Managing*, 3-8 to 3-46  
     configuration manager, *Managing*, 3-1  
     host-based resource files, *Managing*,  
     2-1  
     overview, *Managing*, 1-1  
     work groups, *Managing*, 3-8 to 3-46  
 man pages, *SunOS*, 2-7  
 Media software distribution kit  
   for InfoServer system, *InfoServer*, 1-1

## Memory

- effect of network protocols, *Overview*, 1-7
- resetting VXT factory-default settings, *Appendixes*, A-2
- mkfontdir utility, *ULTRIX*, 2-10; *OSF/1*, 2-11; *SunOS*, 2-9; *HP-UX*, 2-9; *AIX*, 2-10; *SCO*, 2-10
- mkvxtfonts utility, *ULTRIX*, 2-12; *OSF/1*, 2-12; *SunOS*, 2-10; *HP-UX*, 2-10; *AIX*, 2-11; *SCO*, 2-11
- MOM\$LOAD search list, *OpenVMS*, 2-6
- MOP transport
  - booting terminals
    - by Ethernet address, *OpenVMS*, 2-5; *ULTRIX*, 2-7; *OSF/1*, 2-8
    - by VXT image name, *OpenVMS*, 2-6; *ULTRIX*, 2-6; *OSF/1*, 2-7
    - troubleshooting, *ULTRIX*, 2-8
  - booting terminals by Ethernet address, *InfoServer*, 2-5, 2-6
  - downloading VXT images, *Overview*, 1-11
  - enabling, *InfoServer*, 2-5
  - in default booting sequence, *Overview*, 1-11
  - loading VXT software, *ULTRIX*, 2-6; *OSF/1*, 2-7
  - directories, *ULTRIX*, 2-3; *OSF/1*, 2-3
  - MOP-filtering bridge, *InfoServer*, 2-3
  - network bridges and VXT loader file, *Overview*, 1-8
  - troubleshooting MOP loading, *OSF/1*, 2-8
  - VXT loader file, *InfoServer*, 2-3
- MOP trigger, *OpenVMS*, 2-7
  - booting terminals, *ULTRIX*, 2-8; *OSF/1*, 2-9
- mop\_mom listener, *ULTRIX*, 2-6; *OSF/1*, 2-7
- Move Terminals dialog box (CM), *Managing*, 3-34
- .mwmrc file
  - effect on VXT Create pop-up menu, *Managing*, 2-12
- .mwmrc file, *Managing*, 2-11

## N

- Naming conventions
  - system image, *Overview*, 1-12
- Native resource file, *Overview*, 1-3; *Managing*, 1-1
  - definition, *Managing*, 3-3
- NCP commands
  - to configure terminals, *OpenVMS*, 2-5
- Network
  - configuration
    - host-based, *Overview*, 1-3

## Networks

- bridges, *Overview*, 1-8
- configuration
  - server-based, *Overview*, 1-4
- diagnostic tools, *Overview*, 1-8
- management overview, *Overview*, 1-1
- protocol management, *Overview*, 1-2, 1-6, 1-7
- protocol requirements, *Overview*, 1-6
- NeWS bitmap fonts, *SunOS*, 2-11
- NFS transport, *Overview*, 1-17
  - font access, *Overview*, 1-6, 1-17; *AIX*, 2-10
  - font paths, *ULTRIX*, 2-10; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-10
  - terminal customizations, *Overview*, 1-7
- NIS server, *SunOS*, 2-6; *AIX*, 2-7
- NML object
  - DECnet transport, *OpenVMS*, 2-14
- NVRAM
  - synchronizing settings in, *Managing*, 3-27
- NVR-based terminals, *Managing*, 3-6

## O

- Online documents, *Overview*, 1-17
- OpenVMS Authorize Utility, *OpenVMS*, 1-4
- OpenVMS operating system
  - booting terminals
    - MOP by VXT image name, *OpenVMS*, 2-6
    - MOP trigger, *OpenVMS*, 2-7
    - remote node, *OpenVMS*, 2-7
  - character cell terminal services, *OpenVMS*, 2-15
  - DECnet transport
    - system addresses, *OpenVMS*, 2-13
  - downloading VXT software, *OpenVMS*, 2-3
  - error recovery, *OpenVMS*, 1-13
  - fonts
    - access, *OpenVMS*, 2-9
    - compilation and conversion, *OpenVMS*, 2-10
    - support requirements, *Overview*, 1-14
  - hardware requirements, *OpenVMS*, 1-2
  - installation procedure, *OpenVMS*, 1-5
  - installing VXT software on, *OpenVMS*, 1-1
  - LAT/Master, *OpenVMS*, 2-20
  - LAT printer port setup, *OpenVMS*, 2-17
  - LAT services, *OpenVMS*, 2-11
  - management tasks, *OpenVMS*, 2-1
  - MOP
    - booting terminals



## OpenVMS operating system

### MOP

#### booting terminals (cont'd)

##### MOP by Ethernet address,

*OpenVMS*, 2-5

##### network requirements, *Overview*, 1-7

##### paged memory requirements, *OpenVMS*, 2-20

##### postinstallation steps, *OpenVMS*, 2-1

##### print command, *OpenVMS*, 2-17

##### process account limits and quotas,

*OpenVMS*, 1-4

##### required version, *OpenVMS*, 1-1

##### software requirements, *OpenVMS*, 1-2

##### system administration checklist,

*OpenVMS*, 2-1

##### system disk backup, *OpenVMS*, 1-5

##### system parameters, *OpenVMS*, 1-4

##### system startup file, *OpenVMS*, 2-3

##### terminal customizations, *OpenVMS*, 2-16

##### VT1300 booting, *OpenVMS*, 2-7

##### VT1300 terminal, *OpenVMS*, 2-13

##### X services, *OpenVMS*, 2-11

##### XTDRIVER, *OpenVMS*, 2-11

## OpenVMS operating systems

### VXT software

CD-ROM, *OpenVMS*, 1-23

## Options menu (CM), *Managing*, 3-9

## Organization

### of this guide, *Overview*, viii

## Overview, VXT software

### downloading VXT software, *Overview*, 1-9

### font access, *Overview*, 1-13

### font compilation and conversion, *Overview*, 1-14

### fonts provided, *Overview*, 1-14

### host requirements, *Overview*, 1-6

### network protocols, *Overview*, 1-6

### terminal customizations, *Overview*, 1-15

### using protocols, *Overview*, 1-7

### using VXT DECterm, *Overview*, 1-7

### X session support, *Overview*, 1-7

## P

## Paged memory requirements, *InfoServer*, 2-11

## Paging files

### allocation, *InfoServer*, 2-11

### reclaiming, *InfoServer*, 2-12

## Partition names, *InfoServer*, 2-6

## Password

### for InfoServer services, *InfoServer*, 2-9

### host-based terminals, *Managing*, 3-7

### InfoServer system, *InfoServer*, 1-3

### MOP trigger, *ULTRIX*, 2-8; *OSF/1*, 2-9

### VXT\$SERVER account, *OpenVMS*, 1-12

## Password (cont'd)

### VXT manager password, *InfoServer*, 1-4;

*Managing*, 3-3

### changing, *InfoServer*, 2-9

### work group

changing, *InfoServer*, 2-10

### work groups, *Managing*, 3-43, 3-44

## Password dialog box (CM)

### for backing up a terminal, *Managing*, 3-42

### for backing up a work group, *Managing*, 3-40

### for copying a work group, *Managing*, 3-30

### for copying terminals, *Managing*, 3-32

### for creating terminals, *Managing*, 3-13

### for customizing host-based terminals,

*Managing*, 3-21

### for customizing server-based terminals,

*Managing*, 3-21

### for customizing work groups, *Managing*, 3-21

### for deleting a work group, *Managing*, 3-45

### for moving terminals, *Managing*, 3-36

### for removing fonts, *Managing*, 3-52

### VXT manager password, *Managing*, 3-11

## PCF font format, *ULTRIX*, 2-10; *OSF/1*,

2-10; *SunOS*, 2-9; *HP-UX*, 2-9; *AIX*,

2-9; *SCO*, 2-10

## Power-up sequence, *Overview*, 1-11

## Prevent User Customization button (CM), *Managing*, 3-22

## PRINT command, *OpenVMS*, 2-17

## Printer port

### LAT, *OSF/1*, 2-21

setup, *ULTRIX*, 2-21

### OpenVMS system, *OpenVMS*, 2-17

### TCP/IP, *ULTRIX*, 2-23; *OSF/1*, 2-21;

*SunOS*, 2-21; *HP-UX*, 2-15; *AIX*,

2-21; *SCO*, 2-19

### creating printers, *ULTRIX*, 2-25;

*OSF/1*, 2-23; *SunOS*, 2-22;

*HP-UX*, 2-16; *AIX*, 2-22; *SCO*,

2-20

### setting up printers, *ULTRIX*, 2-25;

*OSF/1*, 2-23; *SunOS*, 2-22;

*HP-UX*, 2-16; *SCO*, 2-20

### terminal settings, *OpenVMS*, 2-17;

*ULTRIX*, 2-23, 2-27; *OSF/1*, 2-25;

*SunOS*, 2-23; *HP-UX*, 2-17; *AIX*,

2-23; *SCO*, 2-21

## Printer support utilities

### DEC OSF/1 AXP systems, *Appendixes*, B-3

### ULTRIX systems, *Appendixes*, B-3

### UNIX systems, *Appendixes*, B-3

## Printing

- from host systems, *Overview*, 1–3
- from the host, *OpenVMS*, 2–17; *ULTRIX*, 2–27; *OSF/1*, 2–26; *SunOS*, 2–23; *HP-UX*, 2–17; *AIX*, 2–23; *SCO*, 2–21
- vxtlpd printer daemon, *ULTRIX*, 2–23; *OSF/1*, 2–21; *SunOS*, 2–21; *HP-UX*, 2–15; *AIX*, 2–21; *SCO*, 2–19

## Problems

- installation, *HP-UX*, 1–10

## Process account limits and quotas

- for OpenVMS system, *OpenVMS*, 1–4

## Protocols, *Overview*, 1–6

### requirements

- booting VXT software, *Overview*, 1–11

# R

---

## Read-only terminal, *Managing*, 3–3, 3–22

- Unregistered Terminals work group, *Managing*, 3–4

## Rebooting, *Appendixes*, A–3

## Remote applications

- starting, *OpenVMS*, 2–18; *ULTRIX*, 2–28; *OSF/1*, 2–27; *SunOS*, 2–24; *HP-UX*, 2–18; *AIX*, 2–24; *SCO*, 2–22

## Remote Device List, *InfoServer*, 2–11

## Remote installation, *ULTRIX*, 1–8; *OSF/1*, 1–9; *SunOS*, 1–8; *HP-UX*, 1–8; *AIX*, 1–8

- for SCO ODT system, *SCO*, 1–8

- from a tar file, *SCO*, 1–8

## Resource file, *Overview*, 1–3, 1–18

- See also* Host-based resource file, Native resource file.

- See also* Native resource file, Host-based resource file

- host-based, *Managing*, 1–1

- new terminals, *Managing*, 2–11

- overview, *Overview*, 1–15

- Xrm syntax, *Managing*, 2–1

## Resource Management dialog box (CM),

- Managing*, 3–8

- Backup Terminal dialog box, *Managing*, 3–41

- Backup Work Group dialog box, *Managing*, 3–39

- Change Terminal Password dialog box, *Managing*, 3–44

- Change Work Group Password dialog box, *Managing*, 3–43

- choosing a work group or terminal in, *Managing*, 3–14

- Copy Terminal dialog box, *Managing*, 3–31

## Resource Management dialog box (CM)

### (cont'd)

- Copy Work Group dialog box, *Managing*, 3–29

- Create menu, *Managing*, 3–8, 3–10

- Create Terminal dialog box, *Managing*, 3–12

- Customize Terminal dialog box, *Managing*, 3–23

- Customize Work Group dialog box, *Managing*, 3–22

- displaying servers by group code, *Managing*, 3–14

- File menu, *Managing*, 3–8, 3–14

- finding a work group or terminal, *Managing*, 3–16

- finding terminals, *Managing*, 3–17

- finding work groups, *Managing*, 3–16

- Maintenance menu, *Managing*, 3–9, 3–43, 3–44

- Move Terminals dialog box, *Managing*, 3–34

- Options menu, *Managing*, 3–1, 3–9

- scroll box, *Managing*, 3–8

- Synchronize NVRAM dialog box, *Managing*, 3–27

- updating the list of servers, *Managing*, 3–14

## Resource Management window

- exiting from, *Managing*, 3–46

## Restricted mode

- tftp daemon, *ULTRIX*, 2–4, 2–9; *OSF/1*, 2–4; *SunOS*, 2–4, 2–8; *HP-UX*, 2–4, 2–8; *SCO*, 2–4, 2–9

- rgb.txt file, *Managing*, 2–12

- rm-vxt-kit utility, *Appendixes*, B–1

# S

---

## SCO ODT operating system

- character cell terminal services, *SCO*, 2–17

- downloading VXT software, *SCO*, 2–3

- error messages, *Appendixes*, C–1 to C–4

- files installed, *Appendixes*, B–1 to B–11

- fonts support requirements, *Overview*, 1–14

- hardware requirements, *SCO*, 1–2

- installing VXT software on, *SCO*, 1–1 to 1–17

### local installation

- from QIC 24 or magnetic tape, *SCO*, 1–7

- network requirements, *Overview*, 1–7

- print command, *SCO*, 2–21

- remote installation, *SCO*, 1–8
- from a tar file, *SCO*, 1–8

## SCO ODT operating system (cont'd)

- required version, *SCO*, 1-1
- sample VXT software installation, *SCO*, 1-11
- software requirements, *SCO*, 1-2
- system management tasks, *SCO*, 2-1
- TCP/IP printer port setup, *SCO*, 2-19
- XDMCP support, *SCO*, 2-13
- Server-based image
  - downloading methods, *Overview*, 1-10
- Server-based mode
  - BOOT commands
    - VXT EX software, *Appendixes*, A-2
    - VXT software, *Appendixes*, A-2
- Server-based systems
  - configuration, *Overview*, 1-4
  - overview, *Overview*, 1-4
- Server-based terminal
  - adding to a work group, *Managing*, 3-12
  - choosing for configuration, *Managing*, 3-14
  - configuration manager, *Managing*, 3-2
  - finding for configuration, *Managing*, 3-16
  - host-based resource files, *Managing*, 2-1
  - LASTport group code, *Managing*, 3-2
  - managing, *Managing*, 1-5
  - work group, *Managing*, 3-10
- Servers
  - updating the list of, *Managing*, 3-14
- Service names, *Overview*, 1-12
- SETPRV, *OpenVMS*, 1-2
- SET SERVER LASTPORT GROUP,
  - Managing*, 3-2
- smit utility, *AIX*, 2-22
- SNF font format, *OpenVMS*, 2-10
- SNMP diagnostic tool, *Overview*, 1-8
- Software Options dialog box, *Overview*, 1-17
- Software requirements
  - installation, *InfoServer*, 1-2; *OpenVMS*, 1-2
- Software subsets, *ULTRIX*, 1-3; *OSF/1*, 1-3; *SunOS*, 1-3; *HP-UX*, 1-3; *AIX*, 1-3; *SCO*, 1-3
  - error messages, *Appendixes*, C-1
- Startup menu item, *Overview*, 1-18
- Status messages
  - installation
    - UNIX systems, *Appendixes*, C-3
- Sun fonts
  - conversion kit, *Appendixes*, B-11
- Sun OpenWindows
  - mkfontdir utility, *SunOS*, 2-9
- SunOS operating system
  - character cell terminal services, *SunOS*, 2-19
  - downloading VXT software, *SunOS*, 2-3
  - error messages, *Appendixes*, C-1 to C-4

## SunOS operating system (cont'd)

- files installed, *Appendixes*, B-1 to B-11
- font conversion, *SunOS*, 2-11
- fonts
  - support requirements, *Overview*, 1-14
- installing VXT software on, *SunOS*, 1-1 to 1-18
- keyboard, *Overview*, 1-19
- local installation
  - from a tar file, *SunOS*, 1-7
  - from QIC 24 or magnetic tape, *SunOS*, 1-7
- network requirements, *Overview*, 1-7
- print command, *SunOS*, 2-23
- required version, *SunOS*, 1-1
- sample VXT installation, *SunOS*, 1-11
- software requirements, *SunOS*, 1-2
- system administration checklist, *SunOS*, 2-1
- system management tasks, *SunOS*, 2-1
- TCP/IP printer port setup, *SunOS*, 2-21
- XDMCP support, *SunOS*, 2-14
- Support server
  - copying, *Managing*, 3-51
- Synchronize NVRAM dialog box, *Managing*, 3-27
- SYSPRV, *OpenVMS*, 1-2
- System administration checklist, *OpenVMS*, 2-1; *ULTRIX*, 2-1; *OSF/1*, 2-1; *SunOS*, 2-1; *HP-UX*, 2-1; *AIX*, 2-1; *SCO*, 2-1
- System backup
  - OpenVMS system, *OpenVMS*, 1-5
- System images, *ULTRIX*, 2-3; *OSF/1*, 2-3; *SunOS*, 2-3; *HP-UX*, 2-3; *AIX*, 2-3; *SCO*, 2-3
- DEC OSF/1 AXP systems, *Appendixes*, B-2
- installation choices, *OpenVMS*, 1-3; *ULTRIX*, 1-4; *OSF/1*, 1-4; *SunOS*, 1-4; *HP-UX*, 1-4; *AIX*, 1-4; *SCO*, 1-4
- naming conventions, *Overview*, 1-12
- service names, *InfoServer*, 2-6
- ULTRIX systems, *Appendixes*, B-2
- UNIX systems, *Appendixes*, B-2
- System log file, *ULTRIX*, 2-4; *OSF/1*, 2-4; *SunOS*, 2-4; *AIX*, 2-4; *SCO*, 2-4
- System parameters
  - OpenVMS system, *OpenVMS*, 1-4

## T

TCP/IP printer port, *OSF/1*, 2-21; *AIX*, 2-21; *SCO*, 2-19  
HP-UX setup, *HP-UX*, 2-15  
SunOS setup, *SunOS*, 2-21  
ULTRIX setup, *ULTRIX*, 2-23

TCP/IP transport  
font access, *Overview*, 1-17  
for a remote installation, *ULTRIX*, 1-8; *OSF/1*, 1-9; *SunOS*, 1-8; *HP-UX*, 1-8; *AIX*, 1-8; *SCO*, 1-8  
X services, *OpenVMS*, 2-12, 2-15

Telnet transport  
providing access to, *ULTRIX*, 2-19; *OSF/1*, 2-19; *SunOS*, 2-19; *HP-UX*, 2-13; *AIX*, 2-19; *SCO*, 2-17

Terminal customization files  
service ratings, *Managing*, 3-38

Terminal customizations  
DEC OSF/1 AXP system, *OSF/1*, 2-20  
HP-UX system, *HP-UX*, 2-14  
IBM AIX system, *AIX*, 2-20  
SCO ODT system, *SCO*, 2-18  
SunOS system, *SunOS*, 2-20  
ULTRIX system, *ULTRIX*, 2-20

Terminal emulation, *Overview*, 1-7

Terminal Manager window  
customizing  
for work groups, *Managing*, 3-24  
locking settings  
for a work group, *Managing*, 3-24

Terminal resource file, *Overview*, 1-3

Terminals, managing, *Managing*, 3-8 to 3-46  
backing up, *Managing*, 3-4  
backing up customized settings, *Managing*, 3-40  
choosing a server for, *Managing*, 3-13  
choosing a work group for, *Managing*, 3-13  
copying customized settings, *Managing*, 3-31  
customizing, *Managing*, 3-20  
customizing from the Configuration Manager, *Managing*, 3-24  
deleting, *Managing*, 3-45  
getting started with work groups, *Managing*, 3-2  
locking customized settings, *Managing*, 3-24  
locking DECterm settings, *Managing*, 3-25  
locking window manager settings, *Managing*, 3-26

## Terminals, managing (cont'd)

moving among work groups, *Managing*, 3-34  
using work group settings, *Managing*, 3-23

Terminal window session, *Overview*, 1-1

TFTP  
specifying font sets, *Managing*, 3-50

tftp command, *ULTRIX*, 2-3; *OSF/1*, 2-4; *SunOS*, 2-4; *HP-UX*, 2-4; *AIX*, 2-4; *SCO*, 2-4

tftp daemon  
restricted mode, *SunOS*, 2-4; *SCO*, 2-4  
font paths, *ULTRIX*, 2-9; *SunOS*, 2-8; *HP-UX*, 2-8; *SCO*, 2-9  
unrestricted mode, *ULTRIX*, 2-9; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-9

TFTP daemon  
restricted mode, *ULTRIX*, 2-4; *OSF/1*, 2-4; *HP-UX*, 2-4

TFTP transport  
font access, *Overview*, 1-6  
font paths, *ULTRIX*, 2-9; *OSF/1*, 2-10; *SunOS*, 2-8; *HP-UX*, 2-8; *AIX*, 2-9; *SCO*, 2-9  
network access  
terminal customizations, *Overview*, 1-7

touch command, *ULTRIX*, 2-15; *OSF/1*, 2-15; *SunOS*, 2-15; *AIX*, 2-15

Transport protocols, *Overview*, 1-6

Troubleshooting  
booting error codes, *Appendixes*, A-3  
clearing nonvolatile RAM, *Appendixes*, A-2  
DECnet transport, *OpenVMS*, 2-14  
entering boot commands, *Appendixes*, A-1  
MOP, *ULTRIX*, 2-8; *OSF/1*, 2-8  
network diagnostic facilities, *Overview*, 1-8

tty  
making available, *ULTRIX*, 2-22  
selecting, *ULTRIX*, 2-21

## U

ULTRIX  
system administration checklist, *ULTRIX*, 2-1

ULTRIX operating system  
character cell terminal services, *ULTRIX*, 2-19  
DECnet access, *ULTRIX*, 2-19  
downloading VXT software, *ULTRIX*, 2-3  
error messages, *Appendixes*, C-1 to C-4  
files installed, *Appendixes*, B-1 to B-11



## ULTRIX operating system (cont'd)

- fonts
  - support requirements, *Overview*, 1–14
  - hardware requirements, *ULTRIX*, 1–2
  - installing VXT software on, *ULTRIX*, 1–1 to 1–17
  - LAT access, *ULTRIX*, 2–19
  - LAT printer port setup, *ULTRIX*, 2–21
  - local installation
    - from TK50 or magnetic tape, *ULTRIX*, 1–7
  - management tasks, *ULTRIX*, 2–1
  - network requirements, *Overview*, 1–7
  - print command, *ULTRIX*, 2–27
  - printer port setup, *ULTRIX*, 2–23
  - required version, *ULTRIX*, 1–1
  - sample VXT software installation, *ULTRIX*, 1–11
  - software requirements, *ULTRIX*, 1–2
  - TCP/IP printer port setup, *ULTRIX*, 2–23
  - XDMCP support, *ULTRIX*, 2–14
- Unlocking
  - customized settings, *Managing*, 3–24
  - DECterm settings, *Managing*, 3–25
  - window manager settings, *Managing*, 3–26
- Unregistered Terminals work group, *Managing*, 3–3
- Unrestricted mode
  - tftp daemon, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP-UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
- Update Known Servers (CM), *Managing*, 3–14
- Upgrading VXT software
  - InfoServer system, *InfoServer*, 2–4
- /usr/lib/X11/xdm directory, *OSF/1*, 2–14
- UWS software
  - required version, *ULTRIX*, 1–1

## V

- VAXcluster support, *OpenVMS*, 2–3
- VMSINSTAL, *OpenVMS*, 1–2
  - requirements, *OpenVMS*, 1–5
- VMS system
  - See OpenVMS operating system
- VT1300 terminal, *Overview*, 1–16;  
*OpenVMS*, 2–7
  - booting, *OpenVMS*, 2–7; *Appendixes*, A–1
  - EWS\$SERVER, *OpenVMS*, 2–12
  - loading VXT software, *InfoServer*, 2–6
- vuelogin utility (HP-UX), *HP-UX*, 2–12
- VXT\$BOOT\_BY\_NAME, *OpenVMS*, 2–3, 2–6
- VXT\$INSTALL\_STARTLOGIN, *OpenVMS*, 2–4
- VXT\$INSTALL\_WSA, *OpenVMS*, 2–4
- VXT\$LIBRARY\_PATH, *OpenVMS*, 2–3
- VXT\$SERVER.COM file, *OpenVMS*, 2–12
- VXT\$SERVER account, *OpenVMS*, 1–12
- VXT\$STARTUP.COM
  - customizing, *OpenVMS*, 2–3
- VXT\$STARTUP.COM file, *OpenVMS*, 2–3
- VXT 2000 windowing terminal
  - PCF font format, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–9; *HP-UX*, 2–9; *AIX*, 2–9; *SCO*, 2–10
- vxtcfgtmpl.xrm resource file, *Managing*, 2–1
- VXT Create pop-up menu
  - effected by window manager file, *Managing*, 2–12
- VXT DECterm windows
  - locking settings
    - for a work group, *Managing*, 3–25
  - overview, *Overview*, 1–7
- VXT EX software, *Overview*, 1–2
  - service names, *InfoServer*, 2–6
- VXT font manager, *InfoServer*, 2–8
- VXTLDR.SYS, *InfoServer*, 2–3
- vxtldr image, *ULTRIX*, 1–4; *OSF/1*, 1–5; *SunOS*, 1–4; *HP-UX*, 1–4; *AIX*, 1–4; *SCO*, 1–4
- VXT loader
  - changing the name of, *Overview*, 1–13
- VXT loader file, *InfoServer*, 2–3; *OpenVMS*, 1–3
  - installing on host systems, *InfoServer*, 2–3
- vxtlpd printer daemon, *ULTRIX*, 2–23, 2–24, 2–26; *OSF/1*, 2–21, 2–22, 2–24; *SunOS*, 2–21, 2–22; *HP-UX*, 2–15, 2–17; *AIX*, 2–21, 2–23; *SCO*, 2–19, 2–21
- VXT manager password, *Managing*, 3–3
  - changing, *InfoServer*, 2–9
  - set during installation, *InfoServer*, 1–4
- VXT printer support utilities, *ULTRIX*, 2–23; *OSF/1*, 2–21; *SunOS*, 2–21; *HP-UX*, 2–15; *AIX*, 2–21; *SCO*, 2–19
- VXT software, *Overview*, 1–2
  - BOOT commands, *Appendixes*, A–1
  - booting and downloading, *InfoServer*, 2–3; *OpenVMS*, 2–3; *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP-UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
  - overview, *Overview*, 1–9
  - booting terminals by Ethernet address, *InfoServer*, 2–6
  - default booting process, *Overview*, 1–11
  - files on CD-ROM, *OpenVMS*, 1–23
  - installation
    - See Installation

## VXT software

### installation (cont'd)

- software subsets, *ULTRIX*, 1-3;  
*OSF/1*, 1-3; *SunOS*, 1-3;  
*HP-UX*, 1-3; *AIX*, 1-3; *SCO*, 1-3

### loading

- MOP, *OSF/1*, 2-7
- with IP, *ULTRIX*, 2-3; *OSF/1*, 2-3;  
*SunOS*, 2-4; *HP-UX*, 2-4; *AIX*,  
2-4; *SCO*, 2-3
- with MOP, *ULTRIX*, 2-6
- loading a specific version, *InfoServer*, 2-4
- local clients, *Overview*, 1-16
- network configurations, *Overview*, 1-3
- network management overview, *Overview*,  
1-1
- overview, *Overview*, 1-1
- purging, *InfoServer*, 2-7; *OpenVMS*, 1-14
- removing
  - from UNIX systems, *Appendixes*, B-1
- service names, *InfoServer*, 2-6
- system images, *OpenVMS*, 1-3; *ULTRIX*,  
1-4, 2-3; *OSF/1*, 1-5, 2-3; *SunOS*,  
1-4, 2-3; *HP-UX*, 1-4, 2-3; *AIX*, 1-4,  
2-3; *SCO*, 1-4, 2-3
- creating directories for, *ULTRIX*,  
2-3; *OSF/1*, 2-3; *SunOS*, 2-3;  
*HP-UX*, 2-3; *AIX*, 2-3; *SCO*, 2-3
- naming conventions, *Overview*, 1-12
- selecting, *OpenVMS*, 1-3; *ULTRIX*,  
1-4; *OSF/1*, 1-4; *SunOS*, 1-4;  
*HP-UX*, 1-4; *AIX*, 1-4; *SCO*, 1-4
- Version 2.1 features, *Overview*, 1-17

## VXT system images

- service names, *Overview*, 1-12

## W

### Window manager

- customizing, *Managing*, 2-11
- locking settings
  - for a work group, *Managing*, 3-26

### Work group

- backing up, *Managing*, 3-4
- backing up customized settings,  
*Managing*, 3-38
- change password, *Managing*, 3-43
- choosing for configuration, *Managing*,  
3-14
- copying customized settings, *Managing*,  
3-29
- creating, *Managing*, 3-10
- customization files
  - service ratings, *Managing*, 3-38
- customizing, *Managing*, 3-20, 3-24
- definition, *Managing*, 3-3
- deleting, *Managing*, 3-45

### Work group (cont'd)

- finding for configuration, *Managing*, 3-16
  - for host-based terminals, *Managing*, 3-6
  - getting started, *Managing*, 3-2
  - locking customized settings, *Managing*,  
3-24
  - locking DECterm settings, *Managing*,  
3-25
  - locking window manager settings,  
*Managing*, 3-26
  - managing, *Managing*, 3-8 to 3-46
  - moving terminals to, *Managing*, 3-34
  - passwords
    - changing, *Managing*, 3-43, 3-44
    - policies, *Managing*, 3-5
    - specifying a password, *Managing*, 3-11
  - Unregistered Terminals work group,  
*Managing*, 3-3
- ### Work group password
- changing, *InfoServer*, 2-10
- ### Work Group Settings button (CM),
- Managing*, 3-23

## X

- X11R5 server, *Overview*, 1-17; *ULTRIX*,  
2-13; *SunOS*, 2-13; *AIX*, 2-11; *SCO*,  
2-12
- xdm application, *ULTRIX*, 2-14; *OSF/1*,  
2-14; *SunOS*, 2-14; *SCO*, 2-13
- xdm-config file, *ULTRIX*, 2-15; *OSF/1*,  
2-15; *SunOS*, 2-16; *AIX*, 2-15; *SCO*,  
2-13
- XDMCP support, *ULTRIX*, 2-14; *OSF/1*,  
2-14; *SunOS*, 2-14; *HP-UX*, 2-12;  
*AIX*, 2-13; *SCO*, 2-13
- customizing, *ULTRIX*, 2-14; *OSF/1*,  
2-14; *SunOS*, 2-15; *AIX*, 2-14; *SCO*,  
2-13
- xdm-errors file, *ULTRIX*, 2-15; *OSF/1*,  
2-15; *SunOS*, 2-15; *AIX*, 2-15; *SCO*,  
2-13
- xdm-pid file, *ULTRIX*, 2-15; *OSF/1*, 2-15;  
*SunOS*, 2-15; *AIX*, 2-15; *SCO*, 2-13
- X font utilities
  - DEC OSF/1 AXP systems, *Appendixes*,  
B-3
  - ULTRIX* systems, *Appendixes*, B-3
  - UNIX systems, *Appendixes*, B-3
- XLFD font names, *ULTRIX*, 2-13; *OSF/1*,  
2-13; *SunOS*, 2-13; *HP-UX*, 2-11; *AIX*,  
2-12; *SCO*, 2-12

- X logical font description, *ULTRIX*, 2-13;  
*OSF/1*, 2-13; *SunOS*, 2-13; *HP-UX*,  
2-11; *AIX*, 2-12; *SCO*, 2-12
  - Xreset file, *ULTRIX*, 2-17; *OSF/1*, 2-17;  
*SunOS*, 2-17; *AIX*, 2-16; *SCO*, 2-15
  - Xresources file, *ULTRIX*, 2-15; *OSF/1*,  
2-15; *SunOS*, 2-16; *AIX*, 2-15; *SCO*,  
2-14
  - Xservers file, *ULTRIX*, 2-15; *OSF/1*, 2-14;  
*SunOS*, 2-15; *AIX*, 2-14; *SCO*, 2-13
  - X services, *ULTRIX*, 2-14; *OSF/1*, 2-14;  
*SunOS*, 2-14; *HP-UX*, 2-12; *AIX*, 2-13;  
*SCO*, 2-13
  - DECnet transport, *OpenVMS*, 2-12
  - LAT transport, *OpenVMS*, 2-11
  - OpenVMS system, *OpenVMS*, 2-11
  - requirements, *Overview*, 1-7
  - TCPIP, *OpenVMS*, 2-12
  - Xsession file, *ULTRIX*, 2-16; *OSF/1*, 2-16;  
*SunOS*, 2-16; *AIX*, 2-16; *SCO*, 2-14
  - X session support  
overview, *Overview*, 1-7
  - Xstartup file, *ULTRIX*, 2-16; *OSF/1*, 2-16;  
*SunOS*, 2-16; *AIX*, 2-15; *SCO*, 2-14
  - XTDRIVER, *OpenVMS*, 2-11
  - X window session, *Overview*, 1-1
  - X Window System, *Overview*, 1-1
- Y**
- 
- /ypwhich command, *SunOS*, 2-6

