

VXT Software
On IBM AIX Systems

Insert tabbed divider here. Then discard this sheet

VXT Software

On IBM AIX Systems

January, 1994

This section describes VXT software installation and system management tasks on the IBM AIX operating system.

Internet Address for Reader Comments

You can send your comments and suggestions about this guide and other VXT manuals by electronic mail to the following Internet address:
`docteam@gwen.enet.dec.com`

Revision/Update Information	This is a revised document.
Operating System & Version:	IBM AIX Version 3.1
Software Version:	VXT Version 2.1

**Digital Equipment Corporation
Maynard, Massachusetts**

Related Documents

For information on...	Refer to...
AIX systems	<i>Using the AIX Operating System</i> <i>AIX Operating System Commands Reference</i>
VXT software and VXT 2000 windowing terminals	<i>VXT Software Version 2.1 Release Notes</i> <i>VXT 2000+ / VXT 2000 Windowing Terminal Installing and Getting Started</i> <i>VXT 2000+ / VXT 2000 Windowing Terminal User Information</i> <i>VXT 2000+ / VXT 2000 Windowing Terminal Release Notes</i>

This document was prepared using VAX DOCUMENT Version 2.1.

Contents

1 Installing VXT Software on an IBM AIX System

1.1	Preparing for the Installation	1-1
1.1.1	Checking the Media Software Distribution Kit	1-1
1.2	Installation Procedure Requirements	1-2
1.2.1	Prerequisite Hardware	1-2
1.2.2	Prerequisite Software	1-2
1.2.3	Determining Which Subsets to Load	1-3
1.2.4	Determining Which Images to Install	1-4
1.2.5	Determining Disk Space Requirements	1-4
1.2.6	Backing Up Your System Disk	1-6
1.3	Starting the Installation	1-6
1.3.1	Installing from Local QIC 24 Tape or Magnetic Tape Distribution Media	1-7
1.3.2	Installing from Local tar Files	1-7
1.3.3	Installing from Remote tar Files, Using TCP/IP	1-8
1.4	Responding to Script Prompts	1-9
1.4.1	Error Recovery	1-9
1.4.2	Installation Procedure Is Complete	1-10
1.4.3	Determining and Reporting Problems	1-10
1.5	Sample Installation Session for IBM AIX	1-10
1.6	File Names Installed on Your System	1-16

2 IBM AIX System Management Tasks

2.1	System Administration Checklist	2-1
-----	---------------------------------------	-----

Boot and Downloading

2.2	VXT System Images	2-3
2.3	Creating Directory Structures	2-3
2.4	Loading VXT Software with IP—Host System Setup	2-4

Fonts

2.5	Font Access	2-9
2.5.1	TFTP Font Paths	2-9
2.5.2	NFS Font Paths	2-9
2.6	PCF Font Format for VXT 2000 Windowing Terminals	2-9
2.6.1	UNIX Fonts	2-9
2.7	Compiling Fonts for IBM AIX TFTP Systems	2-10
2.7.1	Font Utilities	2-10
2.7.2	Compiling and Installing Custom Fonts for IBM AIX Systems	2-10
2.8	Managing Fonts	2-11
2.8.1	Alias Names and XLFD Names	2-12

X Services	2-13
2.9 Installing XDMCP support on IBM AIX Systems	2-13
2.10 Customizing Configuration Files for XDMCP Support	2-14
2.10.1 Xservers	2-14
2.10.2 xdm-pid	2-15
2.10.3 xdm-errors	2-15
2.10.4 xdm-config	2-15
2.10.5 Xresources	2-15
2.10.6 Xstartup	2-15
2.10.7 Xsession	2-16
2.10.8 Xreset	2-16
2.10.9 Hints for Configuring	2-17
Character Cell Terminal Services—Telnet	2-19
Managing Terminal and Group Settings	2-20
Printing	2-21
2.11 Setting Up Access to VXT 2000 Printer Ports	2-21
2.11.1 Printing from the IBM AIX Host	2-23
Application Launcher	2-24
 Index	
 Tables	
1-1 Prerequisite Software—IBM AIX Systems	1-2
1-2 VXT Software Subsets—IBM AIX Systems	1-3
1-3 VXT System Images	1-4
1-4 Worksheet for Subset Sizes on IBM AIX Systems	1-5
1-5 Default Locations of Individual Subsets—IBM AIX Systems	1-6
2-1 VXT System Images	2-3

Installing VXT Software on an IBM AIX System

This chapter provides instructions for installing VXT software on computers that are running the IBM AIX operating system. Read the chapter before starting the installation procedure.

1.1 Preparing for the Installation

This section discusses the preparations and requirements for installing VXT software on an IBM AIX system.

Your bill of materials (BOM) specifies the number and contents of your media. Be sure to verify the contents of your kit with this information. If you find missing or damaged parts in your kit, contact your local Digital representative.

1.1.1 Checking the Media Software Distribution Kit

For installations from media, use the BOM to check the contents of your software distribution kit.

The kit includes this installation guide and one of the following:

- A QIC 24 tape cartridge, labeled VXT Software V2.1, for systems with QIC 24 tape drives
- A 9-track magnetic tape (MT9), labeled VXT Software V2.1, for systems with magnetic tape drives

Using the Release Notes

The software kit provides release notes. The documentation kit also provides a hardcopy of the release notes. Digital strongly recommends that you read the release notes before proceeding with the installation.

Operating Environment

VXT Version 2.1 software requires IBM AIX Version 3.1 or later software.

Installing VXT Software on an IBM AIX System

1.2 Installation Procedure Requirements

1.2 Installation Procedure Requirements

This section includes VXT software installation requirements.

Installation Time

The installation takes 20 to 30 minutes, depending on the type of media and your system configuration. Loading fonts generally requires more time for installation than other subsets.

Privileges Needed for Installation

You must log in as a superuser on the system where you are installing the software.

1.2.1 Prerequisite Hardware

To perform the installation you need the following hardware:

- Software distribution device (if installing from media)
You need a distribution device that corresponds with the software distribution media. For example, if you have a QIC 24 tape software kit, you need a QIC 24 tape drive. You must know how to load the media supplied with the software distribution kit on the appropriate drive. the documentation for the tape or disk drive that you are using explains how to load the media.
- Terminal or console workstation
You can use a video terminal, hardcopy terminal, or terminal emulator running on a workstation to communicate with the operating system and respond to prompts from the installation procedure for the software.

1.2.2 Prerequisite Software

Table 1–1 describes the prerequisite software you must use with the VXT software.

Table 1–1 Prerequisite Software—IBM AIX Systems

Prerequisite Products	Purpose
IBM AIX Version 3.1	Provides base system and installation support.
C compiler, program development header files, X or DECwindows header files	Required if you install the VXT BOOTP daemon, printer support utilities, application launcher, and X font utilities.

Your system must be running IBM AIX Version 3.1 or later before you try to install VXT Version 2.1 software, or the installation will fail. See your system documentation for instructions on how to install IBM AIX Version 3.1 software.

Installing VXT Software on an IBM AIX System

1.2 Installation Procedure Requirements

1.2.3 Determining Which Subsets to Load

Use Table 1–2 to choose the software subsets you want to load:

Table 1–2 VXT Software Subsets—IBM AIX Systems

Subset	Description	Recommendation
System images	The load images for supporting network booting by host terminals.	Install on a system designated to provide network booting support (BOOTP) for host terminals.
BOOTP daemon	A BOOTP daemon to provide network service using BOOTP/TFTP.	Do not install. Use your host system's BOOTP daemon to provide network booting (BOOTP) support for host terminals. If your host system does not have a BOOTP daemon, you can use this daemon.
Application launcher	A mechanism that lets terminal users display remote X applications. The launcher supports an rexec function used with the f.exec function in the local window manager.	Install on any system that needs to support remote X applications.
Printer support utilities	Utilities that support printing from a host to the terminal's attached printer, using the TCP/IP network transport for communication.	Install on any system that wants to use the TCP/IP transport to send printing jobs to a terminal's attached printer.
X font utilities	A BDF-to-PCF font compiler and supporting tools to compile custom fonts and man pages for these utilities. The xbdftodump utility retrieves BDF files from any X server.	Install on any system that needs to compile BDF fonts for use by the terminal. (You must have X developers' .h files.) See Chapter 2 for information on using these utilities.
Compiled fonts	Compiled DECwindows and MIT fonts (merged set of all unique fonts). The subset allows you to select 75 dots/in., 100 dots/in., and miscellaneous fonts.	Install on a system designated to provide compiled fonts for terminals and systems that do not already have these fonts.

Notes on Installing Fonts

- If your system already has some or all of the compiled fonts, make sure they are the correct resolution required by the terminal. If not, you need to install the font subsets. Even if you have the compiled fonts, you may want to install the X font utilities supplied in the VXT kit, which make compiling and installing fonts easier.
- If you are installing the compiled fonts provided, they must be installed into a new or empty directory. If you are upgrading from an earlier VXT software version, use the `rm-vxt-kit` script supplied with the earlier version to remove the previous installation files.

Installing VXT Software on an IBM AIX System

1.2 Installation Procedure Requirements

1.2.4 Determining Which Images to Install

Use Table 1–3 to select the system images you want to install.

Table 1–3 VXT System Images

File	Description	Features, Uses, and Memory Requirements
vxt	VXT software	Features: <ul style="list-style-type: none">• All VXT software features• VXT local clients• X image extension (XIE) Uses: <ul style="list-style-type: none">• All VXT 2000 windowing terminals (color, gray scale, and monochrome) Terminal memory requirements (minimum): <ul style="list-style-type: none">• 10 MB
vxtex	VXT EX software	Features: <ul style="list-style-type: none">• Clientless version of VXT software• Simple user interface for making X connections to hosts Uses: <ul style="list-style-type: none">• All VXT 2000 windowing terminals (color, gray scale, and monochrome) Terminal memory requirements: <ul style="list-style-type: none">• 4 MB
vxtldr	VXT loader	Features: <ul style="list-style-type: none">• Loads server-based terminals from an InfoServer system.• Installed as one file, but available under two names (vxtldr and vxtldr1). Uses: <p>Not needed, unless you are loading terminals from an InfoServer system on a different Ethernet segment. In this case, install the VXT loader on a host in the same segment as the terminals.</p>

1.2.5 Determining Disk Space Requirements

This section describes the disk space requirements for the disks that you load the software subsets on.

Table 1–4 lists the disk space requirements for loading the software subsets on IBM AIX software for IBM AIX computer systems. The table specifies disk space requirements by subset.

Installing VXT Software on an IBM AIX System

1.2 Installation Procedure Requirements

Table 1–4 Worksheet for Subset Sizes on IBM AIX Systems

Subset Name	Transient Size (K bytes/Blocks)	Installed Size (K bytes/Blocks)
VXT software images		
VXT software images		
VXT software	6,200/12,400	5,100/10,200
VXT EX software	2,400/ 4,800	1,200/ 2,400
VXT loader	800/ 1,600	400/ 800
VXT BOOTP daemon	80/ 160	40/ 80
Application launcher	700/ 1,400	350/ 700
VXT printer support utilities	400/ 800	200/ 400
X font utilities	1,200/ 2,400	600/ 1,200
Compiled fonts		
75 dots/in	10,120/20,240	5,060/10,120
100 dots/in	19,000/38,000	9,500/19,000
Miscellaneous	12,000/24,000	6,000/12,000
Individual totals:	~53,800/~105,600	~28,100/~56,200

Transient Space

The transient space must be available in the file system containing the installation's working directory. The installed space must be available where the product will reside. These locations may be distributed across multiple file systems.

Add Up Subsets

Using Table 1–4, add up the total values for the subsets you plan to load in each file system. Use this sum to determine the disk space requirement for your installation.

Compare the space required for the subsets with the free space currently on the file systems where the software files will reside.

Determine Free Space

To determine the current amount of free space for a directory path, log in to the system where you plan to install the software and enter the df command. For example:

```
% df -I Return
```

```
Filesystem      Total KB    used    free %used Mounted on
/dev/hd4         4096      3828     268   93% /
/dev/hd2       315392  315368      24   99% /usr
/dev/hd9var      4096      2500    1596   61% /var
/dev/hd3         8192      6196    1996   75% /tmp
/dev/hd1         4096      4096       0  100% /home
adam1:/work1/free_disk1 271847 125742 146105  46% /usr/tftpboot
```

A file system must have enough free space to meet the Table 1–4 space requirements.

Installing VXT Software on an IBM AIX System

1.2 Installation Procedure Requirements

If you have insufficient disk space, you can perform an NFS mount from a server that has sufficient space. For example:

```
% su
# mount -t nfs server:/usr/free_disk /usr/tftpboot
```

Table 1–5 shows the default locations for each subset.

Table 1–5 Default Locations of Individual Subsets—IBM AIX Systems

Subset Name	Default Location
VXT software images	/usr/tftpboot/vxt/images
VXT application launcher	Images and scripts in /usr/local/bin Man pages in /usr/local/man/man1
VXT printer support utilities	Images and scripts /usr/local/bin Documents in /usr/tftpboot/vxt
Man pages in /usr/local/man/man1	
X font utilities	Images and scripts in /usr/local/bin Man pages in /usr/local/man/man1
Compiled fonts	/usr/tftpboot/vxt/fonts/75dpi /usr/tftpboot/vxt/fonts/100dpi /usr/tftpboot/vxt/fonts/misc

1.2.6 Backing Up Your System Disk

Digital recommends that you back up your system disk before installing any software. Use the backup procedures established at your site.

1.3 Starting the Installation

This section provides step-by-step instructions for installing VXT software on an IBM AIX system.

The installation procedure consists of a series of questions requiring user responses, as well as informational messages. See Section 1.5 for a sample installation session.

To end the installation procedure at any time, press **Ctrl** **C**. When you press **Ctrl** **C**, the installation procedure saves the files it has already installed, deletes working directories, and exits the process.

Appendix B lists the possible files and directories created during the installation. After you complete the installation, you can check the `install.flist` file for the list of files actually installed.

There are three ways to start the VXT software installation:

- From a QIC 24 tape or 9-track magnetic tape on a local drive
- From a tar file on a local disk drive
- From a tar file on a remote disk drive, using TCP/IP

The following sections describe each method. In each case, the installation procedure loads the software files onto a disk that belongs to the system you are performing the installation for.

Installing VXT Software on an IBM AIX System

1.3 Starting the Installation

1.3.1 Installing from Local QIC 24 Tape or Magnetic Tape Distribution Media

To start the installation:

1. Mount the media on the appropriate tape drive. Use a nonrewinding tape device for the installation. For example: `/dev/rmt5.1`.
2. Log in as a superuser (login name root) on the system that you are installing the software on.
3. Choose a convenient empty work directory from which to do the installation. Use the `cd` command to move to that directory. If you do not have an empty work directory, you may choose to create a new directory. Make sure there is sufficient transient work space.

For example:

```
# mkdir /usr/vxt      #this may already exist
# mkdir /usr/vxt/kit  #this may already exist
# cd /usr/vxt/kit
```

4. Use the `tar` command to access the kit media in a local tape drive:

```
# tar -xf /dev/rmt5.1
```

`/dev/rmt5.1` is the device name of the source drive that holds the distribution tape. The device name may be different on your system.

5. Execute the shell script with the Bourne shell command `sh`, specifying how to access the installation kit:

```
# sh install.sh /dev/rmt5.1
```

To continue the installation, go to Section 1.4.

1.3.2 Installing from Local tar Files

VXT Version 2.1 software uses two `tar` files. Previous versions used one file. You may need to extract the two `tar` files from the media to files, to allow electronic access by another system.

1. Log in as a superuser (login name root) on the system that you are installing the software on.
2. Choose a convenient empty work directory from which to do the installation. Use the `cd` command to move to that directory. If you do not have an empty work directory, you may choose to create a new directory. Make sure there is sufficient transient work space.

For example:

```
# mkdir /usr/vxt      #this may already exist
# mkdir /usr/vxt/kit  #this may already exist
# cd /usr/vxt/kit
```

3. Use the following two `dd` commands to extract the two `tar` files. In this example, the media device is `rmt5.1`:

```
# dd if=/dev/rmt5.1 of=/usr/vxt/VXT-2.1.tar1 ibs=10k
# dd if=/dev/rmt5.1 of=/usr/vxt/VXT-2.1.tar2 ibs=10k
```

Installing VXT Software on an IBM AIX System

1.3 Starting the Installation

VXT-2.1.tar1 is the first extracted file and contains the installation scripts.

VXT-2.1.tar2 is the second extracted file and contains the files to be installed.

You can specify different file names if desired.

To start the installation procedure:

4. Use the `tar` command to access the first local `tar` file, which contains the installation script:

```
# tar -xf /usr/vxt/VXT-2.1.tar1
```
5. Execute the shell script with the Bourne shell command `sh`, specifying how to access the installation kit in the second local `tar` file:

```
# sh install.sh /usr/vxt/VXT-2.1.tar2
```

To continue the installation, go to Section 1.4.

1.3.3 Installing from Remote tar Files, Using TCP/IP

VXT Version 2.1 software uses two `tar` files. You may need to extract the two `tar` files from the media to files, to allow electronic access by another system.

Use the following two `dd` commands to extract the two `tar` files. In this example, the media device is `rmt5.1`:

```
# dd if=/dev/rmt5.1 of=/usr/vxt/VXT-2.1.tar1 ibs=10k
# dd if=/dev/rmt5.1 of=/usr/vxt/VXT-2.1.tar2 ibs=10k
```

VXT-2.1.tar1 is the first extracted file and contains the installation scripts.

VXT-2.1.tar2 is the second extracted file and contains the files to be installed.

You can specify different file names if desired.

To start the installation procedure:

1. Log in as a superuser (login name `root`) on the system that you are installing the software on.
2. Choose a convenient empty work directory from which to do the installation. Use the `cd` command to move to that directory. If you do not have an empty work directory, you may choose to create a new directory. Make sure there is sufficient transient work space.

For example:

```
# mkdir /usr/vxt/kit
# cd /usr/vxt/kit
```

3. Use the `rsh` command to access the first remote `tar` file, which contains the installation script:

```
# rsh ip_nodename cat /usr/vxt/VXT-V2.1.tar | tar -xf -
```

ip_nodename is the name of the remote node where the `tar` file is retrieved.

Installing VXT Software on an IBM AIX System

1.3 Starting the Installation

To use the `rsh` command, you need appropriate access to the remote machine.

4. Execute the shell script with the Bourne shell command `sh`, specifying how to access the installation kit in the second `tar` file:

```
# sh install.sh rsh ip_nodename cat /usr/vxt/VXT-2.1.tar2
```

To continue the installation, go to Section 1.4.

1.4 Responding to Script Prompts

After you enter the `sh install.sh` command for local or remote (node-specific) installations, the installation script begins. See the sample installation script (Section 1.5).

- Choose the IBM AIX operating environment.
- Choose the subsets that you want to load.
- Respond to the questions for each selected subset.

At each point, you have the option to exit the installation.

After you answer all questions, the script performs the installation. You do not have to be present while the installation is in progress.

1.4.1 Error Recovery

If errors occur during the installation, the system displays failure messages. Errors can occur during the installation if any of the following conditions exist:

- Incorrect operating system version
- Incorrect version of prerequisite software
- Incorrect or missing `.h` or C compiler files for font utilities, `bootpd`, and printer utilities
- Insufficient superuser privileges for a successful installation
- Insufficient quotas for a successful installation
- Insufficient disk space
- Device used was a rewinding device
- Incorrect file accessed using `install.sh` (VXT-2.1.tar1 script was accessed instead of VXT2.1.tar2 kit.)

For descriptions of error messages generated by these conditions, see the IBM AIX system documentation on system messages, recovery procedures, and IBM AIX software installation. If you are notified that any of these conditions exist, you should take the appropriate action described in the message. For information on installation requirements, see Section 1.2.2.

See Appendix C for descriptions of subset error messages, user error messages, and other generic error messages.

Installing VXT Software on an IBM AIX System

1.4 Responding to Script Prompts

1.4.2 Installation Procedure Is Complete

See Chapter 2 for startup requirements, procedures, and system management tasks.

After the installation, the following seven relevant files are in your working directory:

File	Description
install.flst	The list of all files installed on your system as part of the VXT software installation.
install.log	The installation log file.
rm-vxt-kit	A script that lets you remove VXT software from your system. This is useful for removing the files for <i>this version</i> when you next upgrade VXT software. Move this script to a safe place for possible future use.
RelNotes.txt	<i>VXT Software Version 2.1 Release Notes</i> in text format.
vxtivp	Installation verification procedure
vxtpostinstall	Postinstallation checklist
isrd	Utility used by vxtivp

1.4.3 Determining and Reporting Problems

Software Errors

If you encounter a problem while using VXT software, report it to Digital. Depending on the nature of the problem and the type of support you have, you can take one of the following actions:

- Call Digital if your software contract or warranty agreement entitles you to telephone support.
- Submit a Software Performance Report (SPR).

Documentation Errors

If you find an error in the VXT documentation, fill out and submit the Reader's Comments form at the back of the document. Please include the section and page number where the error occurred.

You can also send your comments by electronic mail to the Internet address listed on the title page and Reader's Comments form.

1.5 Sample Installation Session for IBM AIX

This section contains a sample installation from a local file, including all options.

```
% su [Return]
Password:
# cd /usr/vxt/kit [Return]
# tar -xf /usr/vxt/VXT-2.1.tar1 [Return]
# sh install.sh /usr/vxt/VXT-2.1.tar2 [Return]

(c) Digital Equipment Corporation 1992, 1993
DIGITAL VXT Software, Version 2.1
```


Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

This is the installation script for the
DIGITAL VXT Software
Version V2.1

installation kit. The kit contains several subsets. You can choose which subsets you want to install. Each selected subset is extracted into a temporary work area in the current working directory before final installation. Unless you request otherwise, all work areas will be removed after the product is installed.

The installation occurs in two stages. In the first stage, you answer questions on images and subsets. The second stage performs the actual installation of the system images and subsets that you select. You do not need to be present during the second stage.

This script refers you to sections of the VXT Software Version 2.1 Installation and System Management manual for more information on some topics.

Please answer all questions. Default answers are displayed in square brackets ([]). Press Return to choose the default answer. For yes/no answers enter y or n.

Select your system environment or exit the installation.

0. Exit without completing installation
1. Digital ULTRIX
2. SunOS
3. Hewlett-Packard HP-UX
4. IBM AIX
5. SCO ODT
6. DEC OSF/1 AXP

Which environment are you using [4]? :

environment is: IBM AIX

is this correct [y]? :

installing in the IBM AIX environment

Select the subsets to install or exit the installation.

If you select subset 2, 3, 4, or the font compiler utilities in 5, you need a C compiler and program development header files on your host system.

If you specify more than one number, separate each number with a space or a comma.

0. Exit without installing subsets
1. VXT Software Images
2. VXT BOOTP Daemon
3. VXT Host Application Launcher
4. VXT Printer Support Utilities
5. X Font Utilities (font compiler, etc.)
6. Compiled Fonts
7. Converting Sun Fonts for the VXT

You do not need to install the Compiled Fonts if you have already installed them from a VXT Version 2.0 kit.

Which subsets do you want to install [1 3 4 5 6]? :

selecting subsets: images app-launch vxtpd font-utils fonts

is this correct [y]? :

selected subsets: images app-launch vxtpd font-utils fonts

Now you will answer questions for the subsets you have chosen.

Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

This is the installation script for the
VXT Software Load Images
installation kit. You can select which VXT images to install, and
you have the option to specify where you would like the images installed.

See Table 1-3 in the Installing VXT Software on a IBM AIX System chapter
for a description of the images.

Select the VXT images to install or exit the installation.

0. Exit without completing installation
1. VXT loader
2. VXT
3. VXT EX

Install the VXT loader on this system only if you want to support
terminals in server-based mode from an InfoServer on another Ethernet
segment.

Which images do you want to install [2 3]? :

selecting subsets: VXT VXT_EX
is this correct [y]? :

selected subsets: VXT VXT_EX

Where do you want to install the VXT Software Load images?

Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset

[/usr/tftpboot/vxt/images]? :

not a directory: /usr/tftpboot/vxt/images
do you want to create it [y]? :

created: /usr/tftpboot/vxt/images

Where do you want to install the VXT Configuration File Template?

Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset

[/usr/tftpboot/vxt/config]? :

not a directory: /usr/tftpboot/vxt/config
do you want to create it [y]? :

created: /usr/tftpboot/vxt/config

This is the installation script for the

Application Launcher installation kit. You can
specify where to install the Application Launcher image and man pages.
See the System Management Overview and System Management Tasks chapters
for more information on Application Launcher.

Where do you want to install the Application Launcher image?

Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset

[/usr/local/bin]? :

not a directory: /usr/local/bin
do you want to create it [y]? :

created: /usr/local/bin

Where do you want to install the Application Launcher man pages?

Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset

directory [/usr/local/man/man1]? :

Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

```
not a directory: /usr/local/man/man1
do you want to create it [y]? : 
created: /usr/local/man/man1
```

This is the installation script for the
VXT Printer Support Utilities
installation kit. You can specify where to install the
VXT Printer Support Utilities images and man pages.

Where do you want to install the VXT Printer Support Utilities documents?
Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset
[/usr/tftpboot/vxt]? :

destination directory: /usr/tftpboot/vxt
is this correct [y]? :

Where do you want to install the VXT Printer Support Utilities images?
Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset
[/usr/local/bin]? :

destination directory: /usr/local/bin
is this correct [y]? :

Where do you want to install the VXT Printer Support Utilities man pages?
Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset
[/usr/local/man/man1]? :

destination directory: /usr/local/man/man1
is this correct [y]? :

This is the installation script for the
VXT Font Utilities
installation kit. You can select which utilities to install.
The font compiler utilities include the font compiler and mkfontdir. These
are not needed for ULTRIX systems with DECwindows installed, but are needed
to compile fonts on other systems. The font installation utilities make
installing fonts easier on all systems.
You can specify where to install the utilities and manpages.

Select the subsets to install or exit the installation.

- 0. Exit without completing installation
- 1. Font compiler utilities
- 2. Font installation utilities

Which utilities do you want to install [1 2]? :

selecting subsets: compiler_utilities install_utilities
is this correct [y]? :

selected subsets: compiler_utilities install_utilities

Where do you want to install the VXT Font Utilities images?
Enter the absolute pathname of the destination
directory or enter 'q' to quit this subset
[/usr/local/bin]? :

destination directory: /usr/local/bin
is this correct [y]? :

Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

Where do you want to install the VXT Font Utilities man pages?

Enter the absolute pathname of the destination

directory or enter 'q' to quit this subset

[/usr/local/man/man1]? :

destination directory: /usr/local/man/man1

is this correct [y]? :

This is the installation script for the

Compiled Fonts

installation kit. You can install 100dpi fonts, 75dpi

fonts, and miscellaneous fonts. You can specify where to install the fonts.

Select font sets or exit the installation.

0. Exit without completing installation
1. 100 dpi fonts
2. 75 dpi fonts
3. Miscellaneous fonts

Which font sets do you want to install [1 2 3]? :

selecting subsets: 100dpi_fonts 75dpi_fonts misc_fonts

is this correct [y]? :

selected subsets: 100dpi_fonts 75dpi_fonts misc_fonts

Where do you want to install the Compiled Fonts?

Enter the absolute pathname of the destination

directory or enter 'q' to quit this subset

[/usr/tftpboot/vxt/fonts]? :

destination directory: /usr/tftpboot/vxt/fonts

is this correct [y]? :

created: /usr/tftpboot/vxt/fonts

What do you want to do with the temporary working directories?

1. Remove if successful; save if an error occurred (default)
2. Save working directories
3. Remove working directories

Which option do you want? [1]? :

selecting save_on_error working directories

is this correct [y]? :

You have the option of printing or displaying a postinstallation checklist and running an Installation Verification Program to ensure the installation completed successfully.

Should the postinstallation checklist be printed [n]? : **y**

print postinstallation checklist; is that correct [y]? :

What printer would you like the postinstallation checklist to be printed on [default printer]? :

Should the postinstallation checklist be displayed

on the terminal (using more) [n]? :

do not display postinstallation checklist; is that correct [y]? :

Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

Do you want the Installation Verification Procedure (IVP)
to be run after installation [n]? :

do not run the IVP; is that correct [y]? :

If the installation encounters errors from the tar utility: See your IBM AIX
system documentation for an explanation of the error and the appropriate
action to take.

If the installation process fails: Look in the install.log file in the working
directory to find information to help you diagnose the problem.

The installation will take approximately 5 minutes to 20 minutes if you do not
install compiled fonts, and from 10 minutes to 60 minutes if you do install the
compiled fonts. The exact time depends on your system and installation media.

No more questions will be asked. The installation is in progress.

Extracting from media source: /dev/rmt5.1

installing images

installing VXT Software Load Images in
/usr/tftpboot/vxt/images

VXT Software Load Images installation process completed
status: successful installation

installing app-launch

building Application Launcher for IBM AIX

installing Application Launcher in
/usr/local/bin

installing Application Launcher man pages in
/usr/local/man/man1

Application Launcher installation process completed
status: successful installation

installing vxtpd

building VXT Printer Support Utilities for IBM AIX

installing VXT Printer Support Utilities documents in
/usr/tftpboot/vxt

installing VXT Printer Support Utilities documents in
/usr/local/bin

installing VXT Printer Support Utilities documents in
/usr/local/man/man1

VXT Printer Support Utilities installation process completed
status: successful installation

installing font-utils

Installing VXT Software on an IBM AIX System

1.5 Sample Installation Session for IBM AIX

```
building VXT Font Utilities for IBM AIX

installing VXT Font Utilities documents in
    /usr/local/bin

installing VXT Font Utilities documents in
    /usr/local/man/man1

VXT Font Utilities installation process completed
status: successful installation

installing fonts

installing Compiled Fonts in
    /usr/tftpboot/vxt/fonts

Compiled Fonts installation process completed
status: successful installation

Removing temporary working directories.
removing temporary directory images
removing temporary directory app-launch
removing temporary directory vxtlpd
removing temporary directory font-utils
removing temporary directory fonts
Printing postinstallation checklist on default printer

The list of all files installed on your system is in
    /work/kit/install.flist

A script to remove the
    DIGITAL VXT Software
from your system is in
    /work/kit/rm-vxt-kit
You should move this script to a safe place for possible future use.

A postinstallation checklist is in
    /work/kit/vxtpostinstall

The release notes are in
    RelNotes.txt

The installation verification procedure is in
    /work/kit/vxtivp and isrd
You may want to move these scripts to a safe place for possible future use.
To run the installation verification procedure, execute
    /work/kit/vxtivp

The installation log is in
    /work/kit/install.log

DIGITAL VXT Software installation process completed
status: successful installation

#
```

1.6 File Names Installed on Your System

Appendix B lists the possible files installed on your system by the installation procedure. The `install.flist` file lists the files actually installed during your installation.

IBM AIX System Management Tasks

Chapter Overview

This chapter describes system management tasks for using VXT software with the IBM AIX operating system.

The details for performing some procedures on your host system may differ slightly from the procedures described here. In that case, use the procedures in this chapter as a guideline and refer to your operating system documentation for specific instructions.

2.1 System Administration Checklist

The IBM AIX operating system is a supported boot host for VXT 2000 windowing terminals. Before you use an IBM AIX system as a boot host for these terminals, you must perform some minor reconfiguration steps on the host system.

Host and Terminals in the Same Subnet

To download VXT software successfully, the boot host and the VXT 2000 windowing terminal must be in the same subnet.

Checklist

Use the following checklist to ensure that you complete the system management tasks:

☐ Booting and Downloading

☐ VXT system images

Install the VXT system images before starting with system management tasks (Chapter 1).

☐ Directory structure

Configure the system so that the VXT system images and fonts are not on the root file system. You may use symbolic links to other file systems. See Section 2.3.

☐ IP addresses

Contact your network administrator to obtain a unique Internet protocol (IP) address for each VXT 2000 windowing terminal that you plan to boot from your IBM AIX system. Add these addresses to the `/etc/hosts` file on your system; if necessary, update the name server on your network.

☐ Network services

Your host system must provide the boot protocol/trivial file transfer protocol (BOOTP/TFTP).

IBM AIX System Management Tasks

2.1 System Administration Checklist

☐ Boot setup

- **Loading VXT software with IP (BOOTP/TFTP)**

To download VXT software with an IP boot sequence, the host system needs a resident bootp daemon, configured correctly in the `/etc/inetd.conf` file. You also need a corresponding bootptab configuration file.

Section 2.4 includes a sample bootptab file. Use the sample to set up a bootptab entry in the `/etc/bootptab` file.

After you configure the system for IP (BOOTP/TFTP) booting, restart the Internet daemon to initialize the changes you made.

☐ Fonts

VXT software provides fonts in the portable compiled font (PCF) format. If you need to use custom fonts, compile and install fonts in the PCF format. See Sections 2.5 to 2.8.

☐ NFS Access

If you use the NFS transport to access fonts or resource files, those file systems must be exported.

Optional System Management Tasks

☐ X Services

If you plan to use IP X sessions on terminals, make sure your host system supports the X display manager control protocol (XDMCP). If needed, install XDMCP and customize its associated files. See Section 2.10.

☐ Character Cell Services

If you plan to use terminal windows, make sure your host system is configured for Telnet or DECnet access.

☐ Terminal and Group Settings

You can use the terminal's configuration manager or your own host-based resource files to configure and manage terminals. See the *Managing Terminals and Work Groups* section in this guide.

☐ Printing

☐ Printer Ports

Your host system can use the TCP/IP transport to access a serial or parallel printer connected to a VXT 2000 windowing terminal. To set up a printer port, see Section 2.11.

☐ Printer Names

Select ptys and corresponding printer names for each VXT. Add a line in the `/etc/vxtlpdtab` file for each printer.

☐ VXT Application launcher

VXT Version 2.1 software provides an application launcher that lets terminal users send commands to a host to display host X applications on the terminal. For setup procedures, see the Application Launcher section in this chapter.

Booting and Downloading

This section describes the VXT system images, how to create directory structures, and how to download the VXT software using the BOOTP/TFTP protocol.

2.2 VXT System Images

VXT Version 2.1 software provides the following system image files:

Table 2–1 VXT System Images

Install this image . . .	If you want . . .
vxt	VXT software with local clients. This image can run on color, gray scale, and monochrome VXT 2000 windowing terminals with 10 megabytes of terminal memory.
vxtex	VXT EX software without local clients. This image can run on color, gray scale and monochrome VXT 2000 windowing terminals with only 4 megabytes of terminal memory.
vxtldr	To support terminals in server-based mode from an InfoServer system on another Ethernet segment.

VXT BOOTP Daemon You need a daemon to load the system images from an IBM AIX system. The VXT installation kit provides a BOOTP daemon, if your system does not have one.

2.3 Creating Directory Structures

You must log in as the superuser to perform all procedures in this chapter.

Use the following commands to create the directory structure that will contain the VXT system images for IP loading:

```
# mkdir /usr/tftpboot # may already exist
# ln -s /usr/tftpboot /tftpboot # may already exist
```

You can use an alternate location for /usr/tftpboot, such as /var/tftpboot.

2.4 Loading VXT Software with IP—Host System Setup

Perform the following steps to boot the VXT 2000 windowing terminal using IP:

Step 1.
Edit the `/etc/inetd.conf` file.

Find the `bootp` and `tftp` command lines in the `/etc/inetd.conf` file. Your `inetd.conf` may vary depending on your configuration. If you installed the BOOTP daemon in the VXT installation kit, the installation created the daemon file `/usr/local/etc/bootpd` in Berkley format. You can also use a Carnegie Mellon University (CMU) format daemon. Modify these command lines to look like one of the following examples.

Examples

IBM bootpd

```
❶ bootps dgram udp wait root /etc/bootpd bootpd [-d]
```

VXT bootpd

```
❶ bootp dgram udp wait /usr/local/etc/bootpd bootpd [-i] [-d]
```

```
❷ tftp dgram udp wait nobody /etc/tftpd tftpd
```

Explanation of Examples

Make sure to remove the `#` comment character from the beginning of the `bootp` and `tftp` lines.

- ❶ The `bootp` command line causes `/etc/inetd` to start the `bootpd` when the system receives a request for BOOTP services.
 - The `-d` option enables the `bootp` daemon to write messages into the `syslog` file if logging is enabled on your system.
 - The `-i` option allows the `bootp` daemon to run under the `inet` daemon.

Check the syslog Daemon

Verify that the `syslog` daemon is running. The `syslog` file should be stored in `/usr/spool/mqueue/syslog`. Check the `/etc/syslog.conf` configuration file for the location of the `syslog` file.

To view the most recent log entries, enter the following command and substitute the name of your `syslog` file:

```
# tail /usr/spool/mqueue/syslog
```

- ❷ The `tftp` command line causes the `/etc/inetd` process to start the `tftpd` daemon when the system receives a request for TFTP services.

Step 2.
Edit the /etc/bootptab
file.

For each terminal, create an entry in the /etc/bootptab file. If the file does not exist, you must create it. Be sure to maintain the format of the example file. Using the existing entries as examples, create an entry for your terminal.

The Internet protocol host name used in the /etc/bootptab file must be the same as the official host name used in other files that refer to the terminal's IP address. These other files include the /etc/hosts name server database. See your system administration manuals for details.

loadfile Path Name

The loadfile path name specified in the /etc/bootptab file is relative to any restrictions on tftpd. See step 1.

Examples

The following two examples show typical IBM AIX bootptab entries in Berkley and CMU format. Each example has two entries. The first entry is for a terminal named vxtf, running VXT software. The second entry is for a terminal named vxte, running VXT EX software.

The VXT bootpd does not support default and relative pathnames in bootptab. These are supported by the IBM AIX bootpd.

Sample VXT /etc/bootptab Entries—Berkley Format

```
#@(#)bootptab.example
# /etc/bootptab: database for bootp server (/etc/bootp)
#
# Blank lines and lines beginning with '#' are ignored.
#
# home directory
/
# default bootfile
nosuchfile
# end of first section

%%
# The remainder of this file contains one line per client interface
# with the information shown by the table headings below.
# The 'host' name is also tried as a suffix for the 'bootfile'
# when searching the home directory. (e.g., bootfile.host)
#
# host  htype haddr          iaddr          bootfile
#
vxte  1 08:00:2b:25:3e:c6 12.122.128.27 /vxt/images/vxt
vxte  1 08:00:2b:25:3e:c7 12.122.128.28 /vxt/images/vxtex
```

Booting and Downloading

Sample IBM /etc/bootptab Entries—CMU Format

```
# @(#)11 1.6 com/bosboot/bootp/bootptab, bosboot, bos320, 9146320 11/12/91 15:15:36
#
# (C) COPYRIGHT International Business Machines Corp. 1991
# All Rights Reserved
# Licensed Materials - Property of IBM
#
# Permission to use, copy, modify, and distribute this program for any
# purpose and without fee is hereby granted, provided that this copyright,
# permission and disclaimer notice appear on all copies and supporting
# documentation; the name of IBM not be used in advertising or publicity
# pertaining to distribution of the program without specific prior
# permission; and notice be given in supporting documentation that copying
# and distribution is by permission of IBM. IBM makes no representations
# about the suitability of this software for any purpose. This program
# is provided "as is" without any express or implied warranties, including,
# without limitation, the implied warranties of merchantability and fitness
# for a particular purpose.
#
# ORIGINS: 6,27
#
# /etc/bootptab: database for bootp server (/etc/bootpd)
# Blank lines and lines beginning with '#' are ignored.
#
# Legend:
#
#      first field -- hostname
#                      (may be full domain name and probably should be)
#
#      hd  -- home directory
#      bf  -- bootfile
#      gw  -- gateways
#      ha  -- hardware address
#      ht  -- hardware type
#      ip  -- host IP address
#      sm  -- subnet mask
#      tc  -- template host (points to similar host entry)
#      hn  -- name switch
#      bs  -- boot image size
#      T170 -- (xstation only) -- server port number
#      T175 -- (xstation only) -- primary / secondary boot host indicator
#      T176 -- (xstation only) -- enable tablet
#      T177 -- (xstation only) -- xstation 130 hard file usage
#      T178 -- (xstation only) -- enable XDMCP
#      T179 -- (xstation only) -- XDMCP host
#      T180 -- (xstation only) -- enable virtual screen
vxtf.dgg.dec.com:\
bf=vxt:\
hd=/tftpboot/vxt/images:\
ht=ether:\
ha=08002b2b7f71:\
ip=12.345.678.90:
vxtc.dgg.dec.com:\
bf=vxtex:\
hd=/tftpboot/vxt/images:\
ht=ether:\
ha=08002b2b7f72:\
ip=12.345.678.91:
```

Step 3.
Modify /etc/services
file.

You need to modify two lines to match one of the following examples.

The service name should correspond to the service name in `inetd.conf` file.

Examples

Add the following two lines to `/etc/services`, if not already present. Make sure there is not a `#` comment character at the beginning of the lines.

IBM bootp

```
bootps          67/udp          # Provide bootp service.
```

VXT bootp

```
bootp           67/udp          # Provide bootp service.  
tftp            69/udp          # Provide tftp service.
```

NIS Server

If your IBM AIX system is part of a network using network information services (NIS), verify that the master server is updated to include the IP address and host name assigned to each VXT 2000 windowing terminal. Also verify that the master server updates the client systems (slave servers) on the network.

Step 4.
Restart the Internet
daemon.

Restart the Internet daemon to initialize the changes you made to the `/etc/inetd.conf` and `/etc/bootptab` files.

Note

Users cannot connect to the system or load from the system during the short time required to restart the daemon.

Examples

1. You must supply the process ID (PID) of the daemon in the restart command. To display the PID of the `inetd` daemon, use the following command:

```
# ps -ef | grep inetd | sed '/grep/d'
```

Here is a typical system response to the `ps -ef` command:

```
root  5426   1  0  11:46:10 - 0:02  /etc/inetd
```

In this example, 5426 is the PID of the `inetd` process.

2. To restart the `inetd` daemon using this PID, enter the following command:

```
# kill -9 5426 ; /etc/inetd
```

Booting and Downloading

Step 5.
Load the terminal.

After you complete these procedures, you can load the terminal from the newly configured system. Turn on the terminal, then quickly press and release the halt button on the rear of the terminal to display the >>> prompt. At the >>> prompt, enter the following boot command:

```
>>> b/10000 
```

Fonts

2.5 Font Access

This section describes font paths. The VXT 2000 windowing terminal can access fonts by using the TFTP or NFS transport.

2.5.1 TFTP Font Paths

IBM AIX systems are configured for unrestricted tftp. VXT 2000 users must specify the full path to the fonts they plan to access. For example, if you choose the default directory locations for VXT fonts when installing VXT software, you can use the following paths:

```
/tftpboot/vxt/fonts/100dpi/fonts.dir  
/tftpboot/vxt/fonts/75dpi/fonts.dir  
/tftpboot/vxt/fonts/misc/fonts.dir
```

The previous example assumes a symbolic link from /tftpboot to /usr/tftpboot. If you do not use symbolic links, the paths are

```
/usr/tftpboot/vxt/fonts/100dpi/fonts.dir  
/usr/tftpboot/vxt/fonts/75dpi/fonts.dir  
/usr/tftpboot/vxt/fonts/misc/fonts.dir
```

2.5.2 NFS Font Paths

If you use the NFS transport to access fonts or host-based resource files, the file system containing the fonts and resource files must be exported to allow NFS access. Modify the /etc/exports file to list the file system, access privileges, and clients allowed access. Here are examples of exported file systems:

```
/usr/bin                # export to the world  
/usr    -ro             # export as read-only to the world  
/usr/local  -ro vxtc vxtn  # export as read-only to clients  
                # vxtc and vxtn
```

2.6 PCF Font Format for VXT 2000 Windowing Terminals

The terminal requires fonts in the portable compiled font (PCF) format. VXT software can access fonts in big endian and little endian format. If you have existing PCF fonts, you do not need to recompile to use them with the VXT 2000 windowing terminal.

2.6.1 UNIX Fonts

VXT software relies on the fonts.dir file located in each font directory.

Fonts

mkfontdir	<p>If you make any changes in the directories where the fonts are stored, you must update the <code>fonts.dir</code> file using the <code>mkfontdir</code> utility.</p> <p>Use <code>mkfontdir</code> to create a new or updated <code>fonts.dir</code> file. Enter the font paths in the Customize Font Path dialog box, accessed from the Terminal Manager window's Customize menu. See <i>VXT 2000+ / VXT 2000 Windowing Terminal User Information</i> for instructions.</p>
Alternative	<p>If you have network access to fonts on other systems, you can use a facility such as the NFS transport to let this host directly access the fonts. Use <code>mkfontdir</code> to create one common <code>fonts.dir</code> file for all accessible fonts.</p>

2.7 Compiling Fonts for IBM AIX TFTP Systems

This section describes font utilities and how to compile and install custom fonts.

2.7.1 Font Utilities

The VXT software kit for IBM AIX systems includes font utilities. Use these utilities to compile custom fonts for the terminal. Make sure to include the directory where you installed the utilities in your `PATH` variable; the default location is `/usr/local/bin`. The default location for the man pages is `/usr/local/man/man1`. See your host system documentation for information about using man pages.

2.7.2 Compiling and Installing Custom Fonts for IBM AIX Systems

If you have fonts that are not in the PCF format, you can compile fonts and create the `fonts.dir` file with the font utilities supplied. To compile a font, the source font must be in bitmap distribution format (BDF). BDF is the standard source format for fonts used with the X Window System.

First determine the directory to contain the compiled PCF fonts. You must place all fonts that you want to use in the same directory. Create this directory if it does not exist. This directory must contain PCF fonts only, if the font utilities are to work properly.

To compile the fonts:

1. Use the `cd` command to go to the directory containing the source `.bdf` fonts.

Check for Duplicate File Names

Make sure the directory does not contain any `.pcf` files with the same names as the `.bdf` files you are compiling. Any existing `.pcf` files with the same names will be overwritten.

mkvxtfonts

2. Compile the fonts from BDF to PCF, using the `mkvxtfonts` utility:

```
# mkvxtfonts *.bdf
```

If you do not specify a file, the default is `*.bdf`.

This examples assumes that `mkvxtfonts` was installed in this default directory. If `mkvxtfonts` was not installed in `/usr/local/bin`, specify the complete path to `mkvxtfonts`.

instvxtfonts

3. Move the fonts to the destination directory by using the `instvxtfonts` utility:

Check for Duplicate File Names

Make sure the destination directory does not already contain `.pcf` files with the same names as the files you are copying. Any existing files with the same names will be overwritten.

```
# instvxtfonts [-c] path-to-pcf-directory *.pcf
```

path-to-pcf-directory is the path to the directory you want the `.pcf` files to be placed in. You must specify the path. If you do not specify the `.pcf` files, the default is `*.pcf`.

This command moves the specified `.pcf` files from the current directory to the target directory. The command also creates a `fonts.dir` file in the target directory, listing all `.pcf` fonts (new and existing) in the directory.

The `-c` option lets you copy the `.pcf` files to the destination directory instead of moving them.

This example assumes that `instvxtfonts` was installed in this default directory.

Repeat this procedure for each directory containing BDF fonts you want to use.

2.8 Managing Fonts

VXT Version 2.1 software implements the X Version 11 Release 5 (X11R5) server, so you can access fonts from multiple systems, using different transports. If you serve fonts from multiple systems, refer to the *System Management Overview* chapter for requirements.

Fonts

2.8.1 Alias Names and XLFD Names

fonts.alias

Most systems have a `fonts.alias` file that allows fonts to have multiple names. VXT Version 1.2 and later supports the `fonts.alias` file mechanism, so an understanding of the file may be useful. Each line in the file lists two names — an alias name, followed by the actual name of the font to use when the alias is requested.

XLFD

Many applications use the X logical font description (XLFD) naming convention for fonts. The MIT X Window System documentation describes this convention. Fonts with the same XLFD name should be interchangeable. They may look slightly different, but there should be no important differences. Here is an example of an XLFD name:

`-adobe-new century schoolbook-bold-r-normal--10-100-75-75-p-66-iso8859-1`

Generally, aliases are short names for XLFD names, such as `fixed`, `8x13`, and `times_bold14`. In most cases, substituting one font with a similar font does not cause problems. Applications that are particular about their fonts (such as WYSIWYG editors) generally use XLFD names.

X Services

Before you can create IP X sessions on a VXT 2000 windowing terminal, the host system must support the X display manager control protocol (XDMCP).

IBM AIX Version 3.1 Xwindows does not include the `xdm` (X display manager) utility. See Section 2.9 for information on installing XDMCP support.

IBM AIX Version 3.2

IBM AIX Version 3.2 Xwindows provides MIT X11R4 `xdm` support. The default location for the `xdm` executable image is `/usr/lpp/X11/bin/xdm`. The `xdm` configuration files are in the `/usr/lpp/X11/lib/X11/xdm` directory:

```
total 88
-rw----- 1 root    system      44 Aug 24 1992 AuthE9UxXX
-rw-r--r-- 1 root    system    496 May 12 1992 Imakefile
-rw-r--r-- 1 root    system    419 May 12 1992 README
-rw-r--r-- 1 root    system    487 Oct 23 1992 Xresources
-rw-r--r-- 1 root    system    342 Oct 23 1992 Xresources.1
-rw-r--r-- 1 root    system    317 May 12 1992 Xservers.fs
-rw-r--r-- 1 root    system    431 May 12 1992 Xservers.ws
-rw-r--r-- 1 root    system    552 May 12 1992 Xsession
-rw-r--r-- 1 root    system    328 May 12 1992 xdm-config
-rw-r--r-- 1 root    system    259 Apr 29 08:07 xdm-errors
-rw-r--r-- 1 root    system      5 Apr 21 14:16 xdm-pid
```

Refer to the README file for more information on customizing `xdm` on your IBM AIX system. You start `xdm` at each power-up by placing an entry in the `/etc/rc.net` file.

2.9 Installing XDMCP support on IBM AIX Systems

AIX Version 3.1 Xwindows is X11R3-based and does not include `xdm`. AIX Version 3.2 Xwindows includes MIT X11R4 `xdm`.

If you use AIX Version 3.1 Xwindows or do not have `xdm` installed, copy `xdm` from the MIT X11R4 or X11R5 distribution as described in the following procedure.

To provide XDMCP support:

1. If you do not have the following X window applications, copy them from the MIT X11R4 or X11R5 distribution to the `/usr/bin/X11` directory.

```
xdm
xauth
xrdb
xterm
twm
```

Make these files executable by entering the following command:

```
# chmod a+x filename1 [filename2 ....]
```

X Services

2. Copy the following configuration files from the MIT X11R4 or X11R5 distributions to directory `/usr/lib/X11/xdm`:

`Xreset`
`Xresources`
`Xservers`
`Xstartup`
`Xsession`
`xdm-config`

3. If you wish, you may choose to install the man pages from the MIT distribution kit. The man pages describe the X Window System and the applications provided.
4. Customize the configuration files to suit the needs of your environment (Section 2.10).

Files

To install and set up XDMCP support, you must log in as the superuser. After installing `xdm` from the MIT X11R4 or X11R5 kit, you should have the following files on your system:

`/usr/bin/X11/xdm`
`/usr/lib/X11/xdm/Xreset`
`/usr/lib/X11/xdm/Xresources`
`/usr/lib/X11/xdm/Xservers.fs`
`/usr/lib/X11/xdm/Xservers.ws`
`/usr/lib/X11/xdm/Xsession`
`/usr/lib/X11/xdm/Xstartup`
`/usr/lib/X11/xdm/xdm-config`

Section 2.10 describes the purpose of each file and how to customize it.

2.10 Customizing Configuration Files for XDMCP Support

This section describes some files associated with XDMCP support and how to customize them.

2.10.1 Xservers

The `Xservers` file contains a list of X window displays managed by the host `xdm` process. These are displays that do not use XDMCP to communicate with the host `xdm`. Examples are local workstation displays and older (pre-X11R4) X terminals that do not support XDMCP.

XDMCP Recommended

The VXT 2000 windowing terminal can communicate with the host `xdm` using XDMCP, or the host `xdm` can manage the terminal without XDMCP. Digital recommends using XDMCP, because the VXT 2000 windowing terminal will provide more reliable initiation, termination, and reinitiation of `xdm` sessions. XDMCP involves less loading of the host. Allowing the host to manage the terminal is less reliable; this option is provided for backward compatibility and user convenience, but is not recommended.

Creating the Xservers File

The Xservers file must exist, whether or not the host xdm manages the VXT 2000 windowing terminal. If the terminal communicates with the host xdm using XDMCP and the Xservers file does not exist, create an empty file with the touch command:

```
# touch /usr/lib/X11/xdm/Xservers
```

2.10.2 xdm-pid

The xdm-pid file contains the process ID of the xdm parent process. This file is maintained by xdm.

2.10.3 xdm-errors

The xdm-errors file contains a list of errors reported by xdm. If this file does not exist, create an empty version as follows:

```
# touch /usr/lib/X11/xdm/xdm-errors
```

2.10.4 xdm-config

The xdm-config file controls the operation of xdm. The file is read when xdm is first started. If you change this file, you must restart xdm for the changes to take effect.

Example

```
DisplayManager.servers:           /usr/lib/X11/xdm/Xservers
DisplayManager.errorLogFile:      /usr/lib/X11/xdm/xdm-errors
DisplayManager.pidFile:           /usr/lib/X11/xdm/xdm-pid
DisplayManager*resources:         /usr/lib/X11/xdm/Xresources
DisplayManager*session:           /usr/lib/X11/xdm/Xsession
DisplayManager.0.authorize:       true
DisplayManager*authorize:         false
```

2.10.5 Xresources

This file specifies the resources used when displaying the login box. The file also specifies the failsafe client option.

Example

```
xlogin*login.translations: #override\
    <Key>F1: set-session-argument(failsafe) finish-field()\n\
    <Key>Return: set-session-argument() finish-field()
xlogin*borderWidth: 3
#ifdef COLOR
xlogin*greetColor: #f63
xlogin*failColor: red
xlogin*Foreground: black
xlogin*Background: #fdc
#else
xlogin*Foreground: black
xlogin*Background: white
#endif
```

2.10.6 Xstartup

The Xstartup file is executed by xdm after the user has successfully logged in. Be careful when adding commands to this file, because it is executed with superuser privileges. This file is normally empty.

X Services

Example

```
#!/bin/sh
#
# Xstartup
#
# This program is run as root after the user is verified
#
```

2.10.7 Xsession

The `Xsession` file runs after `Xstartup`. Commands in this file are executed with the user's default login privileges.

Example

```
#!/bin/sh
#
# Xsession
#
# This is the program run as the client
# for the display manager. This example is
# quite friendly as it attempts to run a per-user
# .xsession file instead of forcing a particular
# session layout. The .xsession should be executable.
#   chmod a+x .xsession
#

case $# in
1)
    case $1 in
        failsafe)
            exec xterm -geometry 80x24-0-0 -ls
            ;;
        esac
    esac
esac

startup=$HOME/.xsession
resources=$HOME/.Xresources

if [ -f $startup ]; then
    exec $startup
    exec /bin/sh $startup
else
    if [ -f $resources ]; then
        xrdp -load $resources
    fi
    twm &
    exec xterm -geometry 80x24+10+10 -ls
fi
```

2.10.8 Xreset

The `Xreset` file runs after the user logs out. Like `Xstartup`, `Xreset` runs at superuser level. Be careful when adding commands to this file. This file is normally empty.

Example

```
#!/bin/sh
#
# Xreset
#
# This program is run as root after the session terminates, but
# before the display is closed
#
```

2.10.9 Hints for Configuring

Use the `/var` file when the `/usr` file is read-only.

The following hints can help you customize your applications for XDMCP support:

In some systems `/usr` is read-only. To use `xdm` in such systems, create a directory under the root `/var` as follows:

```
# mkdir /var/X11/xdm
```

This step avoids the need for `xdm` to have write access to `/usr`. When you make this change, ensure that the `xdm` configuration file `xdm-config` has correct pointers to the other `xdm` files. For example, if you intend to use the root `/var`, change `/usr/lib/X11/xdm/xdm-config` as follows:

```
DisplayManager.errorLogFile: /var/X11/xdm/xdm-errors
DisplayManager.pidFile: /var/X11/xdm/xdm-pid
DisplayManager.remoteAuthDir: /var/X11/xdm
```

Modify the `xlogin` dialog.

On IBM AIX systems, you can change the appearance of the `xlogin` dialog to be more consistent with VXT and ULTRIX conventions by appending the following lines to the `/usr/lib/X11/xdm/Xresources` file:

```
xlogin.Login.width: 512
xlogin.Login.height: 192
xlogin.Login.*Font: *-Menu-***-120-***-ISO8859-1
xlogin.Login.greeting: IP X Session
xlogin.Login.unsecureGreeting: unsecure IP X Session
xlogin.Login.fail: Login incorrect
```

Modify the `/usr/lib/X11/Xsession` file to start a remote session manager.

On some host systems, a session manager provides the way to start remote X window applications. You can customize `Xsession` to start the session manager instead of the window manager and terminal emulator. For example, on IBM AIX systems you can start the DECwindows session manager `dxsession` by making the following changes to `/usr/lib/X11/Xsession`.

Find these two lines in the file:

```
twm &
exec xterm -geometry 80x24+10+10 -ls
```

Replace those two lines with this line:

```
exec dxsession
```

To start `xdm` each time the host system is rebooted:

Append the following lines to the `/etc/rc.net` file:

```
[ -f /usr/bin/X11/xdm ] && {
    /usr/bin/X11/xdm & echo -n ' xdm' >/dev/console
}
```

X Services

To start `xdm`
manually:

Enter the following command:

```
# /usr/bin/X11/xdm
```

Character Cell Terminal Services—Telnet

To configure your system for Telnet access, see your host system documentation.

You must log in as the superuser.

Managing Terminal and Group Settings

When a terminal uses a host-based VXT system image, the terminal stores its customizations in a native resource file in the terminal's nonvolatile memory (NVRAM). You have two options for centrally managing terminals on your network:

- Use your terminal's configuration manager to manage the settings in the native resource file of each terminal.
- Create your own resource files on a host system and configure terminals to access the files.

See the *Managing Terminals and Work Groups* section of this guide for details.

Printing

2.11 Setting Up Access to VXT 2000 Printer Ports

With VXT Version 2.0 or later software, IBM AIX hosts can use the TCP/IP protocol to access a serial or parallel printer connected to a VXT 2000 windowing terminal.

The printer ports are typically used for printers, but you can attach other devices. You can use the serial port to read data from and send data to the attached device. VXT 2000 hardware restricts the parallel port to sending data only.

Software Requirements

You need the VXT printer support utilities subset provided with the VXT software installation kit. This subset provides the `vxtlpd` VXT printer daemon.

`vxtlpd` Printer Daemon

The `vxtlpd` printer daemon works with the UNIX printer daemon and filters to send data to and from the specified terminal printer port. The `lpd` command on the host communicates with the slave side of a pseudoteletype `pty` as it would to any serial device.

The `vxtlpd` printer daemon reads a configuration file that specifies the `ptys`, the terminal's IP address and port number, and the starting timeout period for retrying a connection. The timeout period doubles each time a connection attempt fails, up to a maximum of 30 minutes.

Configuration File Syntax

You must create the configuration file used with the `vxtlpd` printer daemon. The default name and path for the configuration file is `/etc/vxtlpdtab`. You can use `vxtlpd` to specify a different file. Use the following syntax for configuration file entries:

```
/dev/ptyqf ip_address_or_name 9100 time #optional comment
```

Examples:

```
/dev/ptyqf 1.2.3.4 9100 60
```

```
/dev/ptyqe myvxt 9100 120
```

- Specify the `pty` device used for printing.
- You can specify the terminal's host name or IP address (in dotted decimal notation).
- VXT 2000 windowing terminals use IP port 9100 for the printer.
- The timeout period specifies the time in seconds between retries if the connection to the terminal fails. The maximum timeout period is 30 minutes.

If you specify 0 seconds, then no retries are done. These retries are only done if the terminal is not reachable. If the terminal is reachable but the printer is not ready or not available, the print job will be lost and must be requeued by the user.

Printing

Example: Suppose the starting timeout period is 60 seconds. If a connection is not made after 60 seconds, the timeout period advances to 120 seconds. If a connection is not made after 120 seconds, the timeout period advances to 240 seconds and continues advancing until 30 minutes is reached.

Selecting ptys

Choose the ptys you want to use.

List the ptys. On most systems, you can use the following command to get an alphabetical list:

```
ls /dev/pty*
```

Start with the last pty in the alphabetical list and proceed to earlier ones.

The `vxtlpd` command connects to the master side of the pty. The slave side of the pty is used by the host's printing system. Put the selected ptys and all other required information in the configuration file for `vxtlpd`, then start `vxtlpd`.

Creating Printers

Creating printers for the print subsystem is identical to creating printers directly connected to the system. The procedure differs for each system and each printer type.

In each case, the device for the printer is the slave side of the pty for the corresponding VXT 2000 windowing terminal.

For example, the slave device `/dev/ttyqf` corresponds to the master device `/dev/ptyqf`.

If you do not configure the printer correctly, you may get printing errors, displayed errors messages, or no printout. Among possible solutions, Digital recommends that you manually assign protection to ptys and verify that they are not being used by other users.

Using smit

Use the `smit` utility to create a virtual printer and set the device to the slave side of the pty.

Example: `/dev/ttyqf`

You may have to modify the printer characteristics for the type of printer attached.

Here is the sequence of menu selections in `smit`:

- Devices
- Printer/Plotter
- Manage Local Printer Subsystem
- Add

Create the virtual printer by using the slave side of the pty.

Example: `/dev/typf`

Starting vxtlpd

If you previously installed vxtlpd, kill all the running copies of vxtlpd. Note that this action stops any jobs currently printing on VXT 2000 windowing terminals.

Before starting a new version of vxtlpd:

1. Enter the following command:

```
# ps -ef | grep vxtlpd | sed '/grep/d'
```

2. For each PID, enter the following command:

```
# kill -9 pid
```

To automatically restart vxtlpd each time the system is rebooted, you must edit the /etc/rc.net file. You can also run vxtlpd from the command line.

To run vxtlpd from the command line, use the following format:

```
vxtlpd [-c file] [-l file] &
```

- The *-c file* option lets you specify the configuration file. The default file is /etc/vxtlpdtab.
- The *-l file* option lets you specify a log file for error messages and other messages. If you omit this option, no messages are generated.
- Comments begin with the # character and can continue to the end of the line.

To automatically start vxtlpd when the system is rebooted, add the following lines to /etc/rc.net:

```
[ -x /usr/localbin/vxtlpd ] && {  
  /usr/local/bin/vxtlpd [-c config_file] [-l log_file] > /dev/console  
}
```

Use the correct path to vxtlpd if you installed it in a different location. Specify the *-c* and *-l* options if desired.

Customizing the Printer Port Settings

You must customize the printer port settings on the terminal to match the port and printer in use. For more information, see *VXT 2000+ / VXT 2000 Windowing Terminal User Information*.

2.11.1 Printing from the IBM AIX Host

To submit a printing job from the IBM AIX host to the terminal's printer, use the lpr command.

Syntax

Enter lpr commands as follows:

```
lpr -Pvxt_printer printfile
```

- *vxt_printer* is the name of the printer connected to the terminal. Use the name that was assigned when setting up the printer with the lprsetup command.
- *printfile* is the file to print.

For more information, see the lpr man page.

Application Launcher

Overview	<p>VXT Version 2.1 software provides an application launcher that lets users enter commands from a host session to display remote X applications on the terminal.</p> <p>The host passes remote launching commands to the terminal's local window manager. Users can enter the commands through the VXT Terminal Manager window. Advanced users can use the local window manager to bind commands to mouse buttons, keyboard keys, or terminal menus; this method allows users to start remote X applications without running the terminal manager or a remote session manager.</p>
Installation	<p>The application launcher is part of the VXT software kit. See Chapter 1 for installation instructions.</p> <p>The host system must have a C compiler and X Window System link libraries to build the application launcher.</p>
Security	<p>Users must be authorized to access the terminal from the host system. You can enter authorized hosts and users in the Customize Security dialog box of the Terminal Manager window. You can centrally manage these security settings by using the terminal's configuration manager or a host-based resource file. See the <i>Managing Terminals and Work Groups</i> section.</p>
Setup and Use	<p>The VXT installation procedure automatically builds the executable application launcher file named <code>vxtlaunch</code>. By default, the file is placed in the <code>/usr/local/bin</code> directory. Notify users of the launcher's name and location.</p> <p>To launch an application, a terminal user must</p> <ol style="list-style-type: none">1. Log in to the host.2. Run the application launcher.3. Enter a command to launch the desired remote application. <p>See <i>VXT 2000+ / VXT 2000 Windowing Terminal User Information</i> for details on running the application launcher and entering commands.</p>
Running the Application Launcher	<p>After logging in to the host, the user must start the application launcher. There are several methods to start the launcher:</p> <ul style="list-style-type: none">• Interactively• In the user's <code>.login</code> file• In the <code>.xsession</code> file <p>If a user starts the launcher from a login file, the launcher will run each time the user logs in and consume process space.</p>

Entering Remote Launching Commands

Users can enter launch commands from the Terminal Manager window (Create dialog box). Advanced users can use the local window manager to bind commands to buttons, keys, or menus (Workspace: Customize Resource Configuration dialog box).

Index

A

Alias names, 2–12
Application launcher, 2–24

B

Backup
 system disk, 1–6
BDF font format
 converting to PCF, 2–10
BOOT commands
 IP, 2–8
Bootting terminals, 2–3
 creating directories for VXT images, 2–3
 with IP, 2–4
bootp command, 2–4
BOOTP daemon, 2–2
 creating command entries, 2–4
/bootpd file, 2–7

C

Character cell terminal services, 2–19
Configuration
 host system
 booting terminals, 2–4

D

Daemon
 BOOTP, 2–4
 Internet, 2–4
Directory
 for VXT images, 2–3
Disk space requirements
 installation, 1–4
Documentation, 2

E

Error recovery
 IBM AIX system, 1–9
Errors
 installation, 1–10
/etc/bootptab file, 2–5
 examples, 2–5

/etc/exports file, 2–9
/etc/hosts, 2–1
/etc/services file, 2–7

F

Font
 access, 2–9
 NFS, 2–10
 compiling
 BDF to PCF, 2–10
 TFTP systems, 2–10
 font aliases, 2–12
 font path
 unrestricted tftp, 2–9
 format
 PCF, 2–9
 management, 2–11
 UNIX fonts, 2–9
 XLFD names, 2–12
Font paths
 NFS, 2–9
 TFTP, 2–9
Font utilities, 2–10
fonts.alias file, 2–12

H

Hardware requirements
 IBM AIX system, 1–2

I

IBM AIX operating system
 character cell terminal services, 2–19
 error recovery, 1–9
 hardware requirements, 1–2
 installing VXT software on, 1–1 to 1–16
 local installation
 from QIC 24 or magnetic tape, 1–7
 print command, 2–23
 required version, 1–1
 sample VXT software installation, 1–10
 system disk backup, 1–6
 system management tasks, 2–1
 TCP/IP printer port setup, 2–21
 XDMCP support, 2–13

inetd.conf file, 2-4
Installation, 1-1
 installation time, 1-2
 local, 1-7
 from a tar file, 1-7
 from QIC 24 or magnetic tape, 1-7
 remote, 1-8
 from a tar file, 1-8
 requirements
 disk space, 1-4
 software, 1-2
 superuser privileges, 1-2
 sample session, 1-10
 script prompts, 1-9
 software subsets
 worksheet, 1-3
instvxtfonts utility, 2-11
Internet daemon, 2-2, 2-4
 restarting, 2-7
IP transport
 loading VXT software, 2-4
 directories, 2-3
 VXT boot commands, 2-8

L

Loading VXT software
 See Booting terminals
Local installation, 1-7
Log file, 2-4
lpr command, 2-23

M

Media software distribution kit, 1-1
mkfontdir utility, 2-10
mkvxtfonts utility, 2-11

N

NFS transport
 font access, 2-10
 font paths, 2-9
NIS server, 2-7

P

PCF font format, 2-9
Printer port
 TCP/IP, 2-21
 creating printers, 2-22
 terminal settings, 2-23
Printing
 from the host, 2-23
 vxtlpd printer daemon, 2-21
Problems
 installation, 1-10

R

Release notes, 1-1
Remote applications
 starting, 2-24
Remote installation, 1-8

S

smit utility, 2-22
Software performance report, 1-10
Software requirements, 1-2
Software subsets, 1-3
System administration checklist, 2-1
System backup
 before installation, 1-6
System images, 2-3
 installation choices, 1-4
System log file, 2-4

T

TCP/IP printer port, 2-21
TCP/IP transport
 for a remote installation, 1-8
Telnet transport
 providing access to, 2-19
Terminal customizations, 2-20
tftp command, 2-4
tftp daemon
 unrestricted mode, 2-9
TFTP transport
 font paths, 2-9
touch command, 2-15
Transient space, 1-5

U

Unrestricted mode
 tftp daemon, 2-9

V

VXT 2000 windowing terminal
 PCF font format, 2-9
VXT printer support utilities, 2-21
VXT software
 booting and downloading, 2-3
 installation
 local, 1-7
 remote, 1-8
 software subsets, 1-3
 worksheet for subsets, 1-4
 loading
 with IP, 2-4
 system images, 1-4, 2-3
 creating directories for, 2-3
 selecting, 1-4

vxtldr image, 1–4
vxtlpd printer daemon, 2–21, 2–23

X

X logical font description, 2–12
X services, 2–13
X11R5 server, 2–11
xdm-config file, 2–15
xdm-errors file, 2–15
xdm-pid file, 2–15
XDMCP support, 2–13
 customizing, 2–14
XLFD font names, 2–12
Xreset file, 2–16
Xresources file, 2–15
Xservers file, 2–14
Xsession file, 2–16
Xstartup file, 2–15

